

# HITACHI INVERTER

## HFC-VWA<sub>2</sub> SERIES

### INSTRUCTION MANUAL

Thank you very much for purchasing the Hitachi HFC-VWA<sub>2</sub> series inverter.

This instruction manual is intended for use by the operator of the Hitachi inverter. It describes how to install, handle, and maintain the inverter.

Before starting operation, read this instruction manual carefully for installation, maintenance, and inspection.

After reading this manual, keep it at hand for future reference.

**Hitachi, Ltd.**

**Tokyo Japan**

**N B 4 4 4 E X**

# PRECAUTIONS

**CAUTION 1** : These instructions should be read and clearly understood before working on the HFC-VWA2 series.

**CAUTION 2** : Proper grounds, disconnecting devices and other safety devices and their location are the responsibility of the user and are not provided by Hitachi Ltd.

**CAUTION 3** : Be sure to connect any motor thermal switch or overload device back to the HFC-VWA2 series control circuit to assure that the inverter will shut down in the event of an overload or an overheated motor.

**WARNING 1** : This equipment should be installed, adjusted and serviced by qualified electrical maintenance personnel familiar with the construction and operation of the equipment and the hazards involved. Failure to observe this precaution could result in bodily injury.

**WARNING 2** : The user is responsible for ensuring that all driven machinery, drive train mechanisms not supplied by Hitachi Ltd., and process line material are capable of safe operation at an applied frequency of 150% of the maximum selected frequency range to the AC motor. Failure to do so can result in destruction of equipment and injury to personnel should a single point failure occur.

**WARNING 3** : For protection, install an earth leakage breaker type of a large high-frequency sensitive current to avoid an unnecessary operation. The ground fault protection is not designed to protect personal injury.

## **DANGER HIGH VOLTAGE**



Motor control equipment and electronic controllers are connected to hazardous line voltage. When servicing drives and electronic controllers, there may be exposed components with their cases and protrusions at or above line potential. Extreme care should be taken to protect against shock. Stand on an insulating pad and make it a habit to use only one hand when checking components. Always work with another person in case an emergency occurs. Disconnect power whenever possible to check controllers or to perform maintenance. Be sure equipment is properly grounded. Wear safety glasses whenever working on an electronic controller or electrical rotating equipment.

### **CAUTION:**

Rotating shafts and above ground electrical potentials can be hazardous. Therefore, it is strongly recommended that all electrical work conform to National Electrical Codes and local regulations. Installation, alignment and maintenance should be performed only by qualified personnel.

Factory recommended test procedures, included in the instruction manual, Should be followed. Always disconnect electrical power before working on the unit.

# CONTENTS

Page

<b>1 . INSPECTION UPON UNPACKING</b>	<b>1</b>
<b>2 . PRECAUTIONS FOR HANDLING</b>	<b>3</b>
<b>3 . STRUCTURE</b>	<b>7</b>
<b>4 . INSTALLATION</b>	<b>10</b>
4 . 1 Transport .....	10
4 . 2 Precautions for Installation .....	10
4 . 3 Installation Direction and Space .....	11
<b>5 . WIRING</b>	<b>12</b>
5 . 1 Main Circuit Terminal Location .....	12
5 . 2 Main Circuit Terminal connection .....	13
5 . 3 Control Circuit Terminal Location and Connection .....	16
<b>6 . OPERATION</b>	<b>17</b>
6 . 1 Before Test Run .....	17
6 . 2 Operation Method .....	17
6 . 3 Settings for Each Function Before Test Run .....	18
6 . 4 Test Run .....	21
<b>7 . MAINTENANCE AND INSPECTION</b>	<b>30</b>
7 . 1 Precautions for Maintenance and Inspection .....	30
7 . 2 Check Items .....	30
7 . 3 Measurement Method for I/O Voltage, Current, and Power .....	34
7 . 4 Check Method for Converter and Inverter Modules .....	35
<b>8 . TROUBLESHOOTING AND COUNTERMEASURES</b>	<b>37</b>
8 . 1 Cause and Action to be Taken .....	37
8 . 2 Protection Function .....	40
8 . 3 Troubleshooting .....	43

**9 . HANDLING THE DIGITAL OPERATION PANEL 46**

9 . 1 Name of Each Unit of the Digital Operation Panel and Description ..... 46

9 . 2 Return to Initial Settings (Status Before Delivery) ..... 47

9 . 3 Monitor Mode ..... 48

9 . 4 Function Mode ..... 60

9 . 5 Restart after instantaneous power failure and power source switching from commercial power supply to inverter ... 91

**10 . SPECIFICATION 93**

10. 1 Block Diagram ..... 93

10. 2 PC Board Layout ..... 94

10. 3 Standard Specification ..... 95

10. 4 Description of Terminals ..... 99

10. 5 Variable Resistor and Dip Switch ..... 100

10. 6 Wiring Instruments ..... 100

10. 7 Options ..... 101

**11 . ORDERING SPARE PARTS OR REQUESTING PRODUCT INFORMATION 104**

Appendix Table 1 List of Alarm Errors ..... 105

Appendix Table 2 List of Alarm Errors Having to be Rewritten Forcibly ..... 106

Appendix Table 3 HFC-VWA Series DATA SETTING LIST ..... 107

# 1. INSPECTION UPON UNPACKING

Upon unpacking, check to see:

- No part of the inverter has been damaged during transportation.
- The inverter and its instruction manual are contained in the package.
- The inverter is the ordered one (check the specification plate on the cover surface).







Figure 1 Details of Nameplate

If there is a problem, contact your distributor immediately.





Without Remote Operator  
(Example of 3.5LB2)



With Remote Operator  
(Example of 3.5LD2)

## 2. PRECAUTIONS FOR HANDLING

Before operating the inverter, be sure to confirm that there is no problem on the items indicated below. An incorrect operation is dangerous and may cause damage to the inverter.

### 2.1 Environment Around the Installation Site and Installation Surface

- (1) Avoid a high temperature and humidity and easy-to-dew environment and a place exposed to dirt and dust, corrosive gases, and coolant mist, and select a well-ventilated room free of direct sunlight.
- (2) Select a place free of substantial vibration.
- (3) When the inverter (1.5 to 16LB2, 2.5 to 16HB2) is installed inside the control panel, it can be used within the range of  $-10$  to  $40^{\circ}\text{C}$ . When operating the inverter within the range of  $-10$  to  $50^{\circ}\text{C}$  :
  - Remove the terminal cover and blind cover (see Figure 8).
  - Set the PWM control carrier frequency (F-41) to **12kHz or less** to use the 3.5 to 5.5LB 2 · LF2, and 33 to 50HB2. When **16kHz** is selected, reduce the rated output current by 10 %.
- (4) When the PWM control carrier frequency **16kHz** (**10kHz** for 60 to 75HB2) is selected on 33 to 40LB2 and 33 to 50 HB2, reduce the rated output current by 10% or use within the range of  $-10$  to  $40^{\circ}\text{C}$ .
- (5) Use a nonflammable material such as a steel plate on the wall for installation. (The back of the inverter will generate heat and increase in temperature)
- (6) Set the inverter vertically with a marginal space around.

### 2.2 Input Voltage Class

- (1) **Always confirm that the input power matches the name plate rating of the inverter.**
- (2) **Check that the voltage is 1 – phase 220 to 240 V/50Hz, 60Hz for 200V class and 3 – phase 380 to 415V/50Hz, 400 to 460V/60Hz for 400V class.**

### 2.4 Connection

- (1) **Be sure to ground the grounding terminal (⊕mark).**
- (2) Be sure to connect the power source to the **input** terminal (**R, S, T**), and the motor to the **output** terminal (**U, V, W**). (Malconnections may cause damage to the inverter.)
- (3) To start or stop operation, use the 

正転運転
FWD RUN

, 

逆転運転
REV RUN

, or 

停止
STOP

 button for the remote operator, or the FW or RV terminal. Do not start and stop inverters with power ON/OFF.
- (4) Be sure to connect the control power (**Ro, To**) for 400V class inverter.

### 2.5 Precautions for Setting High Frequency (V/f Characteristics for Higher Than 50 Hz)

The frequency of the HFC-VWA2 series inverter can be set to up to 360Hz by selecting the V/f pattern or 375Hz by adding 15Hz to the maximum frequency.

When a two-pole motor is used, special care should be taken because the number of rotations reaches about 22500 rpm.



Check thoroughly the mechanical strength of the motor or of the machine to be connected to it before frequency selection.

A standard motor (general-purpose motor) is designed at a frequency of 60Hz. When a frequency of more than 60Hz is required, contact the motor manufacturer for approval. (In case of HITACHI IX motor, it is designed to 120Hz)

It is not possible to set frequency to over 135Hz. If necessary, refer to the page 77 and set.

## 2.6 Maintenance and Adjustment

- (1) When the power is turned off, do not touch the charged parts until the POWER lamp or the backlight of LCD on the remote operator goes off for 200V class, and until the CHARGE lamp at the right side of PC Board goes off after the terminal cover is removed for 400V class. (Since the capacitor has a residual voltage, it is dangerous.)
- (2) Static electricity may cause damage to MCU or ICs on the printed circuit and inverter module (PM module). Ground the workbench, soldering iron, and human body beforehand.

## 2.7 Insulation Resistance and Withstand Voltage Tests

Special care should be taken for insulation resistance and withstand voltage tests. Before conducting these tests, be sure to read (3) Insulation resistance test and withstand voltage test in Section 7. 2.

## 2.8 Data Settings

- (1) Storage of Data Values

A memory element is used to store a data value when the power is turned off so that it can be used when the power is turned on again. This data value is stored automatically when the power is turned off.

In the case of a sequence that the reset terminal is turned on when the power is turned off, the above data value can not be stored because the microcomputer is also reset. In this case, disconnect the reset terminal, then turn the power off to store the data value.

There is a limit to the storage count of the memory element. When the data value is changed several times a day the power is turned on or off, the life is about 10 years.

For details on initial settings (data values set by Hitachi before shipment), see the table in Section 9. 2.

- (2) Recording Data Values

It is recommended to record data values (settings made by users) in the record sheet for later services, repair, or various checks, though the inverter has been provided with various facilities for these purposes. Please deliver this sheet to the operator of the inverter.



## 2.9 Standard Set Value (60Hz and Constant Torque)


- (1) The standard output frequency is set to 60Hz and the torque is high start torque (constant torque). When changing the frequency to 50Hz, see Section 9. 4(2)(d).
- (2) The standard motor to be used is the **most suitable motor of 4 poles**. When using any motor other than the above, change the settings as follows:


**Capacity:**  kw **Number of poles:**  P

See the table in Section 9. 4(2)(e).

## 2.10 Emergency Stop Switch Connection

When a remote operator or copy unit (option) is used to operate the inverter, a fault (such as loose contact or disconnection) in the remote operator, cables, or connectors during inverter operation may disable the function of the  key of the remote operator (namely, the inverter operation may NOT be STOPPED by pressing the  key). To cope with this problem, it is recommended to connect an emergency stop switch to the RS or FRS terminal of the inverter.



If the reset signal (RS terminal or reset button) is sent to the inverter unit for five seconds or more, communication between the inverter unit and remote operator (copy unit) will be impossible, and the unit will judge the cable to be broken. In this case,  will be displayed, and operation will be stopped. Turning off reset and pressing a key will reset the unit to allow operation.

## 2.11 Surge voltage suppressor filter across the electric motor terminals, only for 400 voltage class HFC-VWA INVERTER.

In the event of PWM method INVERTER operation, Surge voltage occurs at the motor terminal due to the cable length or cable layout between the motor and the inverter, especially in case of 10m or more cable.

To suppress the voltage, special filters are available.





Please contact the nearest representatives.

## 2.12 Install an earth leakage breaker

The ground fault protection circuit is designed to detect unbalanced current generated between output of the inverter and motor, and to cut off output of the inverter. The protection function is to protect the inverter not to protect man.

Install the earth leakage breaker to input of the inverter in order to protect from electrical shock.

## 2. 12 Precautions for Operation

No.	Operation conditions	Error	Modification	Operation procedure, etc.
1	Trial run of motor	<p>The motor does not run uniformly and the number of rotations does not increase. The current of the motor is pulsed.</p> 	<p>F-00 SLV 1 → SLV 2 CD 5 → CD 6 ⋮ 9</p> <p>(CD: Motor stabilization constant Large CD: Large stabilization gain)</p>	<p>See Section 9.4(3)</p> <p>(When the CD value is large, the number of rotations of the motor is greatly changed when the load is suddenly fluctuated.)</p>
2	Light load, light inertia load	<p>The number of revolutions of the motor does not increase smoothly.</p> 	<p>F-00 SLV 1 → SLV 2 CD 5 → CD 6 ⋮ 9</p> <p>F-41 CARRIER 16kHz → CARRIER 12kHz ↓ 8kHz</p>	<p>See Section 9.4(3)</p> <p>See Section 9.4(3)</p>
3	Accelerate or decelerate the light load or the light inertia load in a short time.	<p>The inverter cannot perform a high start torque operation because the load share of the remote motor is unknown.</p> 	<p>F-00 SLV 1 → VF High start torque</p>	<p>See Section 9.4(3)</p>
4	Parallel operation of motor	<p>When the load is fluctuated, the number of rotations of the motor is changed.</p> 	<p>F-00 SLV 1 → SLV 2 CD 5 → CD 4 ⋮ 1</p> <p>(CD: Motor stabilization constant Small CD: Small overshoot Small stabilization gain)</p>	<p>See Section 9.4(3)</p> <p>(When the CD value is small, the current of the motor increases when the load is suddenly fluctuated.)</p>
5	Suddenly fluctuating load			

# 3. STRUCTURE

## 3.1 Appearance and Name of Each Unit




Figure 2 - 1 Front Appearance

Figure 2 - 2 Back Appearance

## 3.2 Removing and Installing the Terminal Cover

Loosen the screw at the lower part of the terminal cover, and press the cover upward to remove it. Connect the cables to the terminals in this state. When attaching the cover, set the pawls at the upper part of the cover to the holes of the from cover, and press the cover.




Figure 3 Removing the Terminal Cover

### 3.3 Removing and Installing the Front Cover

Loosen the two screws (on the right and left) which can be seen when the terminal cover is removed. Remove the frame cover, sliding it upward. (Do not operate the inverter with the front cover removed because it is dangerous.)




Figure 4 - 1 Removing the Front Cover

Insert the two pawls (on the right and left) at the upper part of the main unit into the rectangular holes of the frame, pulling it toward you. Tighten the two screws (on the right and left) at the lower part of the cover.




Figure 4 - 2 Installing the Front Cover

### 3.4 Removing the Front Blind Cover and Installing the Optional Remote Operator (DOP) and Copy Unit (DRW)


Loosen the screws at the upper and lower parts of the front blind cover, and pull the top of the cover upward to remove it.



Figure 5 - 1 Removing the Front Blind Cover



Figure 5 - 2 Top of the Front Blind Cover



For remote operation, connect a cable to the remote operator connector after removing the front blind cover. Cut off the pawl on the top of the cover in an arrow direction (see Figure 5 - 2), then attach the cover.

Note 1



Figure 6 - 1 Remote Operation

When installing the remote operator inside the main unit, connect the cable to the remote operator connector, and set the operator in place. Tighten the screws at the upper and lower parts.

Note 2




Figure 6 - 2 Installing the Remote Operator in the Main Unit

Note 1: Insert the connector vertically.

Note 2: When installing the remote operator on the front cover, it is recommended to use the DOP-03EA (cable length 0.3m).

## 4. INSTALLATION

### 4.1 Transport

Transport the inverter carefully to prevent damage.  
Do not apply force to the front cover.



Figure 7 How to Carry the Inverter

### 4.2 Precautions for Installation (See Section 2.1 for a better understanding.)

- (1) When the installation surface is not even, put some plates under the inverter mounting legs to eliminate gaps beforehand. When the inverter is installed with gaps uneliminated, a distortion caused by the installation may affect the main circuit element, causing damage to the inverter.
- (2) Use a nonflammable material such as a steel plate on the wall for installation. (A heating element is equipped with on the back. It may increase up to about 150°C depending on the operation procedure.)
- (3) The inverter generates heat of about 5% of the rated capacity. Special care should be given to ventilation when the inverter is installed inside the control panel.
- (4) When a plurality of inverters are installed in the control panel, arrange them in two rows on the right and left. When the inverters are stacked, the ambient temperature of the top inverter may rise, causing a fan overheat trip.
- (5) When installing the inverter in the control panel, remove the terminal cover at the lower part of the front and the blind cover. (For 1.5 to 11LB2 · LF2, and 2.5 HB2 to 11 HB2, a blind cover is provided. See Figure 8.)





Figure 8 Appearance of the Inverter



Part A of the front cover as viewed from the inside

Figure 9 Removing the Blind Cover

### 4.3 Installation Direction and Space

Be sure to install the inverter vertically for cooling. Keep the inverter away from other parts and the wall as shown in Figure 10. Foreign substances within the inverter may cause damage to it. Keep the inverter free of foreign substances.





Figure 10 Installing the Inverter



# 5. WIRING


## 5.1 Main Circuit Terminal Location




Type	Terminal location	Terminal screw diameter	Terminal width(mm)
1.5-5.5LB 2 1.5-3.5LD 2 5.5LF 2 2.5-5.5HB 2		Main circuit	M 4 9.7
		Ground	M 4 —
8-11LB 2 8-11LF 2 8-11HB 2		Main circuit	M 5 13
		Ground	M 6 —
16LB 2 16LF 2 16HB 2		Main circuit	M 5 13
		Ground	M 5 —
22LB 2 40-50HB 2		Main circuit ground	M 6 17
		Control power	M3.5 8.5
33-40LB 2 60-75HB 2		Main circuit ground	M 8 23
		Control power	M3.5 8.5
22-33HB 2		Main circuit ground	M 5 13
		Control power	M3.5 8.5

## 5.2 Main Circuit Terminal Connection

### (1) Wiring of the Power Supply and Motor




Note 1: If the output terminal (U, V, W) is carelessly applied with a voltage instead of the input power terminal (R, S, T), the inverter is not only damaged but also the operation is dangerous. When the motor is switched to the commercial power supply by the inverter, the same problem is caused. Mg 1 and Mg 2 should be provided with a mechanical interlock.




Note 2: When the frequency and the operation command are set in case of power failure for 200V class inverter, the operation resumes when the power failure is recovered. It is recommended MgO be installed on the input side for safety.

Note 3: There is no means provided for human body protection against a leakage current. Therefore, install a leak breaker. (Select an earth leakage breaker of a large high-frequency sensitive current to avoid an unnecessary operation.)

Note 4: Ground as specified (for example, ground is accordance with local legal requirements). Separate the grounding pole of the inverter from that of another power electrical equipment. Never use the same pole for both. When a plurality of inverters are used, the grounding cables should not be looped.




- Note 5: When the inverter is operated or stopped by turning Mg 0 and Mg 2 ON or OFF, an OC trip is caused by an overcurrent due to the direct start. If this occurs repeatedly, the element is damaged. Use the control terminal or the remote operator to operate or stop the inverter.
- Note 6: Wiring of the control circuit power terminals connecting R, S, and T allow the 200V class inverter to operate normally without Ro and To. However, to keep a trouble display or to restart the inverter after a power failure is recovered, or to use 400V class inverter, Ro and To are required. In this case, insert a wire. protection fuse(or a breaker)and supply current from the main power supply.
- Note 7: Be sure not to insert a phase advance capacitor or a surge absorber between the inverter output terminal and the motor.
- Note 8: Be sure to connect the control power(Ro, To)for 400V class inverter. Without connecting, the inverter can not operate.



#### Precautions for wiring


When executing the wiring work or another work, attach a cover on the vent hole (slit) on the top of the inverter to prevent wire chips, weld spatters, iron scraps, or dust from falling into the inverter.



(2) Wiring of Regenerative Braking External Resistors (RB1, RB2, RB3)


Regenerative braking internal resistors are connected to the P and RB terminals. When the operation specification of a high-frequency load requires external braking resistors, remove the internal resistors and connect the external resistors.

The terminals of the removed internal resistors should not be left as they are. Insulate the terminals securely or connect them all to the terminal as shown in the figure below.




(3) Wiring of Optional Regenerative Braking Units (BRD-E, BRD-S) for 200V class inverter.

Wiring of optional regenerative braking units which are required due to high braking time duty.




### 5.3 Control Circuit Terminal Location Connection



Note 1: The COM terminal is used only for the AR and RUN terminals and isolated from the other terminals. The L terminal is a common terminal to the other terminals. Do not take COM for L. Be sure not to ground both terminals.


Note 2: Use twisted shielding wires as signal lines, and process each shielding wire as shown in the figure below. The wire length should not be longer than 20 m. When a length of more than 20 m is required, use a VX application controller RCD-A (a remote control panel) or CVD-E (an isolation signal converter).



Note 3: When using a contact to turn on or off a frequency setting signal, use a relay with a cross-bar twin contact which is free of a contact error at a micro-current and voltage.

Note 4: Use relays free of a contact error at 12 VDC and 3 mA for the other contacts.

Note 5: Separate the wires from those of the main circuit and relay control circuit. When they should be crossed, cross them perpendicularly to each other.



# 6 . OPERATION

## 6 . 1 Before Test Run

Before starting the test run, check the following items.

- (1) **Ground the grounding terminal** ( $\oplus$  mark).
- (2) The power lines (input terminals R, S, and T, output terminals U, V, and W, and braking unit terminals P, RB, and N) are correctly connected. (The U, V, and W terminals should not be taken for the R, S, and T terminals.)  
Connect Ro and To for 400V class inverter.
- (3) The signal lines are correctly connected.
- (4) Other than the specified terminals are not grounded.
- (5) The inverter is mounted on the wall. A nonflammable material such as a steel plate is used as a mounting surface.
- (6) After wiring, no parts are short-circuited by wire chips or the amplifier. No tools are left.
- (7) The output wires are not short-circuited or grounded.
- (8) No screws and terminals are loose.

Execute the insulation resistance test and the withstand voltage test with reference to section 7.2. Other than the specified terminals should not be subject to the above tests.

## 6 . 2 Operation Method

The following operation patterns are available for the HFC-VWA<sub>2</sub> series including an optional remote operator and copy unit.

Command Pattern	Frequency command		Operation command		Remarks
	External command from terminal	Optional command	External command from terminal	Optional command	
• 1	✓	/	✓	/	As delivered from factory (All Model)
2	/	✓	/	✓	Operation by remote operator (Option)
* 3	/	✓	✓	/	
4	✓	/	/	✓	


Note 1 : \*mark means operations from the optional remote operator and copy unit. For further details, refer to the Section 9 or individual instruction manuals. When using the remote operator and copy unit, change the switches on their backs. See Section 9 . 3 (2) (a).


Note 2 : With Remote Operator (LD 2 , LF 2) is standard setting to pattern 2 .

### 6.3 Settings for Each Function Before Test Run

#### (1) Setting of General Data

The functions of this inverter are set to standard data. When changing any of the set data, see Chapter 9. This section describes the contents of the standard settings of several functions which are often used.

Function name	Standard settings		Indication of standard settings	Description of data change
V/f pattern (F-00)	220 V, 60Hz is set. Voltage  Output frequency 50Hz		SLV 1 F 60-60 SLV 1 K <span style="border: 1px dashed black; padding: 2px;">  </span> K ↑	See page 65.  Use the function mode for setting.
	Note 1 The maximum frequency of the frequency command is 60Hz. Example : 0 to 10 V : 60Hz at 10 V 0 to 5 V : 60Hz at 5 V 4 to 20 mA : 60Hz at 20 mA		The most suitable motor is set. Example) 5.5LB2 3.7kW SLV 1 P 4 P	When using another capacity and number of poles, be sure to change the settings.
Speed change time (F-01) (F-02)	10 seconds		ACCEL-1 10.0S DECEL-1 10.0S	See page 68. Use the function mode for setting.
Frequency command	Without remote operator LB, 2HB2	Terminal (Change to the remote operator is available)	F-SET-M terminal F/R-SW terminal	See pages 53 to 54. Use the monitor mode for setting.
	With remote operator LD2, LF2 Note 2	Remote operator	F-SET-M Remote F/R-SW Remote	
Frequency setting	Without remote operator LB, 2HB2	Terminal (Change to the remote operator is available)	FS000.0	See pages 52. Use the monitor mode for setting.
	With remote operator LD, 2LF2 Note 2	Remote operator		

Function name	Standard settings	Indication of standard settings	Description of data change
Electronic thermal level (F -23)	<p>The thermal level is a general-purpose motor protection level, and set to 100% of the rated current of the inverter. Set the thermal level to a percent(%)value which provides the current of the moter at 60 Hz given on the rating plate.</p> <p>Example :</p> <p>5.5 kVA motor, 3.7kW, 4 poles            Inverter rated current 16.5 A            Rated motor current : 15 A</p> <p>Thermal level set value = <math>\frac{15}{16.5} \times 100 = 90</math></p>	E-therm 100%	See pages 75. Use the function mode for setting.
External frequency setting • Start • End (F -26) (F -27)	<p>The start frequency and the end frequency for an external analog command of 4 to 20 mA, 0 to 10 V or 0 to 5 V are set. The standard setting is 0, and no additional setting is required.</p> <div style="text-align: center;">  </div>	F-START 000.0 Hz F-END 000.0 Hz	See page 76. Use the function mode for setting.

**Note :**

- (1) When the start frequency and the end frequency are changed by the external frequency setting function, the set data is changed.
- (2) When the inverter with remote operator is used, setting is not have to be changed.




(2) Precaution 1 after Data Setting

**Precaution after Data Setting**

To store data changed by the **機能 FUN** key, press the **記憶 STR** key. When the power is off, data is stored in an element (EEPROM) which can store it after the power is turned off. Data is stored in the Power OFF state (it can be checked by the indicator being turned off). When the RESET switch is turned on simultaneously with Power OFF, no data is stored. For this reason, turn the signal at the reset terminal off, then turn the power off. When data is stored, it is retained even if the reset operation is performed. The figure below shows a circuit requiring an emergency output break.


No data is stored



A symbol X designates a weak current relay which operates in the same way as Mg.

When changed data is not stored after power is turned off, it is reset in the figure above, hence it is not stored.


Data is stored




RS used	• Connect SW as shown above. To store data, turn the SW off and turn power off. Then, turn the SW on.
FRS used	• Even if FRS is used instead of RS, an emergency break is available.

Use FRS for emergency break.

(3) Precaution 2 after data setting



To store date changed by the **モニタ MON** key with only control circuit terminals (Ro, To) connected, or to turn power off, perform the following




(The frequency is changed to 60 Hz.)


Note : When power is turned off unless the **機能 FUN** and **記憶 STR** keys are pressed, an ERROR EEPROM error may be displayed when power is turned on again. Perform the reset operation using the reset terminal, change the data again, if required, and perform the above operations.

## 6.4 Test Run

### (1) Precautions on Operation Sequence




**Figure 11 Main Circuit Power and Controlpower Signal Input Sequence  
(Forward Operation)**




- Turn on the main power Mg, and input the operation command(FW).
- When the operation command is inputted first and Mg is turned on, a direct start results and an overcurrent trip occurs.

(2) Operation Procedure



**The frequency is set and the operation or stop command is externally executed. (Terminals FW and RV)**

In this example, the operation box (OPE-4M, OPE-8M) is used for operation.







Note 1: The 200V class inverter is normally operated unless the control circuit terminals (Ro, To) are connected. Be sure to connect the terminals in the following cases and in case of 400V class inverter

- (a) The voltage is switched to the commercial voltage or the inverter restarts after an instantaneous power failure is recovered.
- (b) The fault display should be left.
- (c) The alarm relay should be activated in case of a under-voltage or instantaneous power failure trip.

Note 2: When Ro and To are connected, fit a power supply protection fuse EF (250V, 3A).

Note 3: When the frequency and the operation command are set in case of power failure, the operation resumes when the power failure is recovered. It is recommended Mg be installed on the input side for safety. For further details, see Fig. 11.



Operation procedure	Description
<p style="text-align: center;"><b>Power ON</b></p>	<p>When the power is turned on, the POWER lamp comes on.</p> 
<p style="text-align: center;"><b>Operation command</b></p>	<p>Turn the switch of the operation box (OPE) from STOP to FWD :</p>
<p style="text-align: center;"><b>Frequency setting</b></p>	<p>Forward</p>  <p style="text-align: right;">(STOP to REV : Reverse)</p>
<p style="text-align: center;"><b>Stop</b></p>	<p>When the frequency is set by turning the frequency setter of the operation box, the motor starts running.</p> 
	<p>When the switch of the operation box is turned from FWD to STOP, the motor decelerates and stops according to the preset deceleration time.</p> 
















**Initial selection when the frequency is set and the inverter is operated or stopped via the digital operation panel**

Operation Procedure	Description
<pre> graph TD     A[Power ON] --&gt; B[Selection of frequency commanding method]     B --&gt; C[Selection of operation commanding method]     C --&gt; D[Selection of frequency setting mode]     D --&gt; E[To Operation Patterns 2, 3, and 4]                     </pre>	<p>When power is turned on, the display before power-off appears. (See Section 9.3(2).)</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> <u>F</u>S 000.0 000.0 Hz         </div> <p>Press the or  key once to select the frequency commanding method.</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> <u>F</u>-SET-M Terminal         </div> <p>Move the cursor to the position of T by using the  key, and press the  key to select the Remote mode.</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> <u>F</u>-SET-M Remote         </div> <p style="margin-left: 40px;">└─ Cursor movement ─┘</p> <p>Press the or  key twice to select the operation commanding method.</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> <u>F</u>/R-SW Terminal         </div> <p>Move the cursor to the position of T by using the  key, and press the  key to select the Remote mode.</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> <u>F</u>/R-SW Remote         </div> <p style="margin-left: 40px;">└─ Cursor movement ─┘</p> <p>Move the cursor to the original position and press the  or  key several times to select the frequency setting mode.</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> <u>F</u>S 000.0 000.0 Hz         </div>


• Simple test running method using Operation Pattern 2

The values necessary for operation are all set except the frequency. The operation procedure using only the digital operation panel is as follows. See Section 9.3(2) for more details.

- Set the frequency.
- The forward or reverse command is set in the Remote mode or via the digital operation panel. When the frequency is set, the inverter starts operation by pressing the  or  key.

Operation procedure	Digital operation panel	Digital display	Description
Power ON		 <p>Cursor</p> <p>Set frequency      Output frequency</p>	When power is turned on, the set frequency and output frequency are displayed on the same screen. When power is turned on next or later, the screen displayed before power is turned off is displayed.
Frequency setting	<p>Move the cursor to the cursor-positioned digit by the  key, and set the frequency by the  and  keys.</p>	<p>(45 Hz setting example)</p>   <p>Cursor</p>	This is a set frequency or output frequency display screen.
Operation	<p>Press the  or  key.</p> <p>Move the cursor by the  key, and change the set frequency by the  and  keys.</p>	<p>Changes in frequency are displayed on the upper right of the same screen.</p> <p>(Example of setting of 30 Hz and deceleration)</p>  <p>Or R</p>	Move the cursor in units of digits to set 45.0.
Acceleration or deceleration			Press the  key for forward operation or the  key for reverse operation. The motor starts softly.
Stop	<p>Press the  key.</p>		When the set frequency is changed during operation the speed is accelerated or decelerated immediately to the set value.
			When the key is pressed, the motor is decelerated to stop.

**The frequency is set and the operation or stop command is executed via the digital operation panel.**



Note 1: The 200V class inverter is normally operated unless the control circuit terminals (Ro, To) are connected. Be sure to connect the terminals in the following cases and in case of 400V class inverter


- (a) The voltage is switched to the commercial voltage or the inverter restarts after an instantaneous power failure is recovered.
- (b) The fault display should be left. (See Section 6.3(3).)
- (c) The alarm relay should be activated in case of an under-voltage or instantaneous power failure trip. (When Ro and To are not connected, the power is broken, or the voltage is decreased, "POWER OFF" is displayed and the motor stops.)

Note 2: When Ro and To are connected, fit a cable protection fuse EF (250V, 3A).

Note 3: The standard setting should be changed. With reference to the initial setting, operate the inverter as specified below.

Operation Procedure	Description
<p style="text-align: center;"><b>Power ON</b></p>	<p>When power is turned on, the display before power-off appears. (See Section 9.3(2).)</p> <div style="border: 1px solid black; padding: 5px; display: inline-block;">             FS 000.0 000.0 Hz         </div> <p style="margin-left: 20px;">↑ Cursor</p>
<p style="text-align: center;"><b>Initial selection</b></p>	<p>Perform initial selection on the previous page to display the following.</p> <div style="border: 1px solid black; padding: 5px; display: inline-block;">             FS 000.0 000.0 Hz         </div> <p style="margin-left: 20px;">↑ Cursor</p>
<p style="text-align: center;"><b>Frequency setting</b></p>	<p>Move the cursor by the  key and enter the set frequency by the  and  keys.</p> <div style="border: 1px solid black; padding: 5px; display: inline-block;">             FS 040.5 000.0 Hz         </div> <p style="margin-left: 20px;">↑ Cursor</p>
<p style="text-align: center;"><b>Operation command</b></p>	<p>Press the  key for forward operation or the  key for reverse operation.</p> <p>Move the cursor by the  key, and enter the set frequency by the  and  keys once again. The speed is accelerated or decelerated immediately.</p>
<p style="text-align: center;"><b>Acceleration or deceleration</b></p>	<ol style="list-style-type: none"> <li>1. Press the  key. The motor starts deceleration immediately according to the preset deceleration time and stops.</li> <li>2. Set the frequency to 0. Move the cursor by the  key and set the frequency to 0 by the  key. The motor decelerates according to the preset deceleration time and stops.</li> </ol>
<p style="text-align: center;"><b>Stop</b></p>	

The frequency is set via the digital operation panel and the operation or stop command is executed externally (FW, RV).



Note 1: The 200V class inverter is normally operated unless the control circuit terminals (Ro, To) are connected. Be sure to connect the terminals in the following cases and in case of 400V class inverter

- (a) The voltage is switched to the commercial voltage or the inverter restarts after an instantaneous power failure is recovered.
- (b) The fault display should be left. (See Section 6.3(3).)
- (c) The alarm relay should be activated in case of a under-voltage or instantaneous power connected, the power is broken, or the voltage is decreased, "POWER OFF" is displayed and the motor stops.)


Note 2: When Ro and To are connected, fit a cable protection fuse EF (250V, 3A).

Note 3: When the frequency and the operation command are set in case of power failure, the operation resumes when the power failure is recovered. It is recommended Mg be installed on the input side for safety. For further details, see Figure. 11.

Operation Procedure	Description
<p style="text-align: center;"><b>Power ON</b></p>	<p>When power is turned on, the display before power-off appears. (See Section 9.3(2).)</p>
<p style="text-align: center;"><b>Selection of frequency commanding method</b></p>	<p style="text-align: center;">F S 0 0 0 . 0      0 0 0 . 0 H z</p> <p>Press the <span style="border: 1px solid black; padding: 2px;">モード MON</span> or <span style="border: 1px solid black; padding: 2px;">▲</span> key once to select the frequency commanding method.</p>
<p style="text-align: center;"><b>Selection of frequency setting mode</b></p>	<p style="text-align: center;">F - S E T   - M      T e r m i n a l</p> <p>Move the cursor to the Position of T by using the <span style="border: 1px solid black; padding: 2px;">▶</span> key, and press the <span style="border: 1px solid black; padding: 2px;">▼</span> key to select the Remote mode.</p>
<p style="text-align: center;"><b>Frequency setting</b></p>	<p style="text-align: center;">F - S E T   - M      R e m o t e</p> <p style="text-align: center;">└─ Cursor movement ─┘</p> <p>Move the cursor to the original position and press the <span style="border: 1px solid black; padding: 2px;">モード MON</span> or <span style="border: 1px solid black; padding: 2px;">▼</span> key several times to select the frequency setting mode.</p>
<p style="text-align: center;"><b>Operation command</b></p>	<p style="text-align: center;">F S 0 0 0 . 0      0 0 0 . 0 H z</p> <p>Move the cursor by the <span style="border: 1px solid black; padding: 2px;">▶</span> key and enter the set frequency by the <span style="border: 1px solid black; padding: 2px;">▲</span> and <span style="border: 1px solid black; padding: 2px;">▼</span> keys.</p>
<p style="text-align: center;"><b>Acceleration or deceleration</b></p>	<p style="text-align: center;">F S 0 4 0 . 5      0 0 0 . 0 H z</p>
<p style="text-align: center;"><b>Stop</b></p>	<p>The forward operation is selected by turning the terminal FW-L on or the reverse operation is selected by turning the RV-L on. Move the cursor by the <span style="border: 1px solid black; padding: 2px;">▶</span> key, and enter the set frequency by the <span style="border: 1px solid black; padding: 2px;">▲</span> and <span style="border: 1px solid black; padding: 2px;">▼</span> keys once again. Open between the PC board terminals FW-L and RV-L. The motor decelerates according to the preset deceleration time and stops. In the terminal mode, the motor is stopped by pressing the <span style="border: 1px solid black; padding: 2px;">停止 STOP</span> key. The <span style="border: 1px solid black; padding: 2px;">停止 STOP</span> key can be invalidated by selection. (See page 80).</p>



**The frequency is set externally and the operation or stop command is executed from the digital operation panel.**



Note 1: The 200Vclass inverter is normally operated unless the control circuit terminals(Ro, To)are connected. Be sure to connect the terminals in the following cases and in case of 400V class inverter

- (a) The voltage is switched to the commercial voltage or the inverter restarts after an instantaneous power failure is recovered.
- (b) The fault display should be left. (See Section 6.3(3).)
- (c) The alarm relay should be activated in case of a under-voltage or instantaneous power failure trip. (When Ro and To are not connected, the power is broken, or the voltage is decreased, "POWER OFF" is displayed and the motor stops.)

Note 2: When Ro and To are connected, fit a cable protection fuse EF(250V, 3A).

Operation Procedure	Description
<p style="text-align: center;"><b>Power ON</b></p>	<p>When power is turned on, the display before power-off appears. (See Section 9.3(2).)</p>
<p style="text-align: center;"><b>Selection of operation commanding method</b></p>	<p style="text-align: center;">FS 000.0 000.0 Hz</p> <p>Press the <span style="border: 1px solid black; padding: 2px;">モニタ MON</span> or <span style="border: 1px solid black; padding: 2px;">▲</span> key twice to select the operation commanding method.</p>
<p style="text-align: center;"><b>Operation command</b></p>	<p style="text-align: center;">F/R-SW Terminal</p> <p>Move the cursor to the Position of T by using the <span style="border: 1px solid black; padding: 2px;">▶</span> key, and press the <span style="border: 1px solid black; padding: 2px;">▼</span> key to select the Remote mode.</p>
<p style="text-align: center;"><b>Frequency setting</b></p>	<p style="text-align: center;">F/R-SW Remote</p> <p style="text-align: center;">└ Cursor movement ─┘</p> <p>Move the cursor to the original position and press the <span style="border: 1px solid black; padding: 2px;">モニタ MON</span> or <span style="border: 1px solid black; padding: 2px;">▼</span> key several times to select the frequency setting mode.</p>
<p style="text-align: center;"><b>Stop</b></p>	<p style="text-align: center;">FS 000.0 000.0 Hz</p> <p>{ Press the <span style="border: 1px solid black; padding: 2px;">正転運転 FWD RUN</span> key for forward operation. F is displayed. { Press the <span style="border: 1px solid black; padding: 2px;">逆転運転 REV RUN</span> key for reverse operation. R is displayed. (Since the set frequency is not entered, the motor does not start running.)</p>
<p style="text-align: center;"><b>Frequency setting</b></p>	<p>Enter one of the items (A frequency setter between H, O, and L 0 to 10 VDC or 0 to 5 VDC between O and L 4 to 20 mA between OI and L)</p>
<p style="text-align: center;"><b>Stop</b></p>	<p>Press the <span style="border: 1px solid black; padding: 2px;">停止 STOP</span> key.</p>

3) Example of connecting the motor with a brake




Figure 12 Connection Example (A Motor with a Brake Used)

## 7. MAINTENANCE AND INSPECTION

The inverter consists of many parts, and will not fulfill the function unless those parts operate normally. Therefore, it is necessary to detect fault signs of the parts and equipment early by periodic inspection and to take measures for them.

Before starting maintenance and inspection

When the inverter is to be restarted, some of the preset data may have to be changed. It is recommended to check the preset data once again before starting maintenance and inspection.

### 7.1 Precautions for Maintenance and Inspection

- (a) Before starting maintenance and inspection, turn the power off.
- (b) Before starting maintenance and inspection, check that the charge lamp on each PC board goes off after the power is turned off. (About 50 VDC remains immediately after the indicator goes off. Check that the voltage between the main circuit terminals P and N is reduced to less than 15V. About 20 seconds for 5.5LB 2 · LF 2 and 33LB 2 about 1 minutes for 5.5HB 2 and 16LB 2 and about 3 minutes for 11HB 2, and about 4 minutes for 33HB 2 and about 6 minutes for 75HB 2.)
- (c) When connecting or disconnecting each connector, do not pull the cable.
- (d) Take special care not to misconnect each connector.

#### • General precautions

Always keep the inverter clean and away from dust. Give special care to disconnection or misconnection, and secure the terminals and connectors. Note that electronic equipment is not resistant to moisture and oil mist, and the insulation is affected by dust or iron powder, causing unexpected trouble.

### 7.2 Check Items

- (1) Daily inspection
- (2) Periodic inspection (yearly or so)
- (3) Insulation resistance test and withstand voltage test

Short-circuit the terminals as shown below, and conduct the tests under the conditions given below.

- Insulation resistance test : Measure the resistance between the terminal indicated below and the ground with a dynamic 500V megohm-meter. The resistance should not be less than 5 MΩ. (Do not use a battery megohm-meter.)
- The withstand voltage test is not required to be conducted. When the test is required, apply 1500VAC between the terminal indicated below and the ground for one minute. No error should occur. (Apply AC 2000V for 1 minute to 400V class inverter)
- Do not use another terminals for the withstand voltage test.
- Increase the application voltage for the insulation resistance test or the withstand voltage test slowly, and then decrease it slowly to 0 V. Sudden voltage application or reduction may cause damage to the inverter module (PM).




Figure 13 Insulation Resistance Test and Withstand Voltage Test

Table 1 Daily Inspection and Periodic Inspection

Unit to be checked	Part to be checked	Check time	Inspection cycle		Check method	Criteria	Standard replacement years	Measuring instrument
			Daily	Periodic				
Entire	Environment General equipment Supply voltage	Ambient temperature and humidity, dust, harmful gas, oil mist	✓		See the precautions in Section 2.	Ambient temperature : -10 to 40°C, no freezing Ambient humidity : 20 to 90% RH, no dew	Thermometer Hygrometer	
		Vibration, noise	✓		Visual and auditory check	No error	Tester	
		Main circuit voltage, control voltage	✓		Measure the voltage between inverter terminals L 1, L 2 and L 3.	200~220V 50Hz (for 200V) 200~230V 60Hz (class) 380~415V 50Hz (for 400V) 400~460V 60Hz (class)		
		(1) Insulation resistance test (between main circuit terminal and grounding terminal) (2) Loose tightening parts (3) Overheated parts (4) Cleaning		✓	(1) See Section 7.2	(1) See Section 7.2	500 V class megohm meter	
Main circuit	General	(1) Distorted conductor (2) Turn or degraded cable cover (crack, discoloration, etc.)		✓	(1), (2) Visual check	(2), (3) No error		
		Offensive odor, buzzing	✓		Auditory check	No error		
		Damaged terminal		✓	Visual check	No error		
		Resistance between terminals		✓	See Section 7.4	See Section 7.4	Analog tester	
	Smoothing capacitor	(1) Leaked liquid		✓	(1), (2) Visual check	(1), (2) No error		
		(2) Protruded or swollen safety valve (3) Electrostatic capacity		✓	(3) Use a capacity meter	(3) Min. 85% of rated-capacity	5 years (Note 1)	
	Relay conductor	(1) Beeping during operation (2) Timer operation time (3) Roughed contact			(1) Auditory check	(1) No error		
		(1) Large crack, discoloration (2) Disconnection		✓	(1) Visual check (2) Disconnect one end, and measure the resistance with a tester.	(1) No error (2) An error of max. +10% of displayed resistance	Tester	

Unit to be checked	Part to be checked	Check time	Inspection cycle		Check method	Criteria	Standard replacement years	Measuring instrument
			Daily	Periodic				
Control circuit	Operation	(1) Inter-phase output voltage balance when only the inverter is operated.		✓	(1) Measure the voltage between inverter output terminal U, V and W Phases.	(1) Inter-phase voltage difference 2% max.	—	
		(2) Protection and display circuits after the sequence test is conducted		✓	(2) Operate the inverter protection circuit imitatively.	(2) Should be operated without errors		
Protection circuit	Whole	(1) Offensive odor, discoloration	✓	✓	Visual check	No error (Note 2)		
	PC board	(2) Excess rust	✓	✓	Visual check			
Cooling system	Cooling fan	Leaked liquid, deformation	✓	✓	(1) Operate the fan by hand with no voltage applied.	The fan should rotate smoothly.	2 to 3 years	
		(1) Vibration, noise	✓	✓	(2) Tighen	No error		
		(2) Loose connection (plug, screw, etc.)	✓	✓	Visual check	The display should be read (Note 3)		
Display	Display of digital operation panel	(3) Dirt, dust	✓	✓			7 years	
		(1) Display status	✓	✓				
		(2) Defective or damaged connector contact	✓	✓				
		(3) Defective lamp	✓	✓				

Note 1: Note that the life of the inverter is extremely shortened when it is used at a high temperature and heavy load. When replacing the capacitor in use with a capacitor which is stored for more than three years, age it under the conditions indicated below before use.

1. First, apply a voltage equivalent 80% of the rated voltage to the capacitor at room temperature for one hour.
2. Next, apply a voltage equivalent to 90% of the rated voltage to it for one hour.
3. Finally, apply the rated voltage to it at room temperature for five hours.

Note 2: Precautions for handling the PC board and inverter module

Both the PC board and inverter module need not be maintained under normal use. If maintenance and inspection and required, the following should be taken into consideration :

Electrostatic damage prevention

The IGBT of the inverter module or the MCU or IC on the PC board may be electrostatically damaged. Be sure to ground the workbench, soldering iron, and human body beforehand.

Note 3: The display may not be easily seen depending on the view angle due to a liquid crystal but should be read.

It is recommended to always keep parts indicated below to shorten the non-operation time.

Table 2 Recommended Spare Parts

Parts	Sequence symbol	Quantity		Remarks
		In use	Spare	
Inverter module	PM	1 - 3	1 - 3	
Cooling fan	FAN	1	1	Unnecessary for 1.5LB2 · LD2
Converter module	DM	1 - 3	1 - 3	
Smoothing capacitor	CB	1 - 2	1 - 2	Store them at -20 to +30℃
PC board	Control board	1	1	The PC board is exclusive
PC board	BRD PC board	1	1	1.5~5.5LB2 · LF2
PC board	FAN PC board	1	1	22~40LB2, 22~75HB2

### 7.3 Measurement Method for I/O Voltage, Current, and Power

General measuring instruments for I/O voltage, current, and power are indicated below. The voltage to be measured is a fundamental wave effective voltage and power to be measured is a total effective value.




Table 3 Parts to be Measured


Measurement item	Parts to be measured	Measuring instrument	Remarks	Reference value
Supply voltage $E_1$	Between R and S, S and T, T and R ( $E_R$ ) ( $E_S$ ) ( $E_T$ )	Moving-iron type voltmeter or rectifier type voltmeter	Fundamental wave effective value	Commercial supply voltage (200V class) 180-242V 50Hz 180-253V 60Hz
Supply current $I_1$	R, S, T ( $I_R$ ) ( $I_S$ ) ( $I_T$ )	Moving-iron type ammeter	Total effective value	
Supply power $W_1$	Between R and S, S and T ( $W_{11}$ ) ( $W_{12}$ )	Electrodynamic type wattmeter	Total effective value	
Supply power factor $pf_1$	Calculate the supply power factor from the measured supply voltage, $E_1$ , supply current $I_1$ and supply power $W_1$ . $Pf_1 = \frac{W_1}{\sqrt{3} \cdot E_1 \cdot I_1} \times 100(\%)$			
Output voltage $E_0$	Between U and V, V and W, W and U ( $E_U$ ) ( $E_V$ ) ( $E_W$ )	See page 33 or use a rectifier type voltmeter	Total effective value	
Output current $I_0$	U, V, W ( $I_U$ ) ( $I_V$ ) ( $I_W$ )	Moving-iron type ammeter	Total effective value	
Output Power $W_0$	Between U and V, V and W ( $W_{01}$ ) ( $W_{02}$ )	Electrodynamic type wattmeter	Total effective value	
Output power factor $Pf_0$	Calculate the output power factor from the output voltage $E_0$ , output current $I_0$ , and output power $W_0$ . $Pf_0 = \frac{W_0}{\sqrt{3} \cdot E_0 \cdot I_0} \times 100(\%)$			

Note 1: Use a meter indicating a fundamental wave effective value for voltage, and meters indicating total effective values for current and power.

Note 2: The inverter output waveform is a distorted wave, and a low frequency may cause an error. However, the measuring instruments and methods indicated provide comparatively accurate values.

Do not use a tester because it is not suitable for distorted waveform.

### Measurement method for output voltage




### 7. 4 Check Method for Converter and Inverter Modules

Note :

- Turn power off and check that the voltage between P and N is reduced to less than 15 VDC before starting operation.
- Use a tester (set to 1 Ω range).

### Check method for the converter module




Tester terminals - → +	Resistance
~ → ~ 3 Ways (R-S, S-T, R-T or equivalent)	50 kΩ or more
P(+)-→ each terminal	50 kΩ or more
Each terminal →P(+)	50 kΩ or less
N(-)-→ each terminal	50 kΩ or less
Each terminal →N(-)	50 kΩ or more

Note : Check the converter module itself.



## Check method for the inverter module (PM)





Inverter module unit



### Outline of inverter module (PM)

### External view of braking transistor (TRS)

Note : The inverter may be electrostatically damaged. Ground the human body beforehand.





### Assembled inverter unit

### Disassembled inverter unit

Tester terminal color Black – Red	Resistance	Part to be checked	Tester terminal color Black – Red	Resistance	Part to be checked
P – U	50 kΩ or more	U phase upper arm	B U – U +	50 kΩ or more	U phase upper arm
P – V		V phase upper arm	B V – V +		V phase upper arm
P – W		W phase upper arm	B W – W +		W phase upper arm
N – U	50 Ω or less	U phase lower arm	B X – U	50 kΩ or more	U phase lower arm
N – V		V phase lower arm	B Y – W		V phase lower arm
N – W		W phase lower arm	B Z – W		W phase lower arm
U – P	50 Ω or less	U phase upper arm	U – B U	50kΩ or more	U phase upper arm
V – P		V phase upper arm	V – B V		V phase upper arm
W – P		W phase upper arm	W – B W		W phase upper arm
U – N	50 kΩ or more	U phase lower arm	U – B X	50 kΩ or more	U phase lower arm
V – N		V phase lower arm	V – B Y		V phase lower arm
W – N		W phase lower arm	W – B Z		W phase lower arm
N – RB	50 Ω or less	Braking transistor (TRS) Note : 1.5 to 5.5LB2 · LF2 : On the PC board			
RB – N	50 kΩ or more				

# 8. TROUBLESHOOTING AND COUNTERMEASURES

When the inverter causes an error, check the cause and take appropriate action by referring to the table below before restarting operation. When no cause is found, its parts are damaged, or problems occur, please contact your distributor.



	Reset method
A	Operate the breaker or the electromagnetic contactor.
B	Short - circuit between the PC board terminals RS and L.

## 8.1 Cause and Action to be Taken

Symptom				Fault cause	Reset method	Check points	Countermeasures	
MCB operation	Mg operation	(Note 2) Error display (?ERROR )	Alarm relay					
✓	—	—	—	Error between the power MCB and inverter output terminal	A	<ul style="list-style-type: none"> <li>• Is the power source short-circuited?</li> <li>• Is the MCB capacity correct?</li> <li>• Is the inverter or power source grounded?</li> </ul>	<ul style="list-style-type: none"> <li>• Repair the short-circuited part.</li> <li>• Increase the MCB capacity.</li> <li>• Repair the grounded part.</li> </ul>	
							Is the converter module damaged?	Replace or repair the converter module.
							Is the magnet switch of the inverter normal?	Replace or repair the magnet switch.
							Is the rush current control resistor of the inverter normal?	Replace or repair the rush current control resistor.
✓		OC Accel OC Decel OC Drive GND Flt	—		A	<ul style="list-style-type: none"> <li>• Is the inverter module damaged?</li> <li>• Is the motor or cable grounded?</li> </ul>	<ul style="list-style-type: none"> <li>• Repair or repair the motor.</li> <li>• Repair the grounded part.</li> </ul>	
	✓	—	—	Power failure	A	• power failure?	• Repair the power source.	
							• Is the contact of the MCB or Mg defective?	Replace the MCB or Mg.
		Under. V	✓	Voltage error (undervoltage)	A	Is the direct motor or large capacity motor of the same power system in operation?	Check the power supply capacity.	
							Is the contact of the MCB or Mg defective?	Replace the MCB or Mg.
		Inst. P-F	✓	Power supply error (instantaneous power failure)	A	<ul style="list-style-type: none"> <li>• Is the contact of the MCB or Mg defective?</li> <li>• Is power turned on when the inverter displays <b>POWER OFF</b> after the power is turned off?</li> </ul>	<ul style="list-style-type: none"> <li>• Replace the MCB or Mg.</li> <li>• Turn power on after the inverter display is erased.</li> <li>• When the load is low, the <b>POWER OFF</b> display time is increased.</li> </ul>	

Note 1 : POWER lamp on front cover indicates fault display.

Note 2 : When an optional remote operator or copy unit is connected, the error contents are displayed.

Symptom				Fault cause	Reset method	Check points	Countermeasures
MCB operation	Mg operation	(Note 2) Error display (?ERROR / / / / )	Alarm relay				
		Over V.	✓	Overvoltage of DC smoothing circuit	B	<ul style="list-style-type: none"> <li>• Is the supply voltage 264 V (200V class) 506 V (400V class) or more?</li> <li>• Is the phase advance capacitor turned on or off?</li> <li>• Is the operation speed suddenly decelerated?</li> </ul>	<ul style="list-style-type: none"> <li>• Decrease the supply voltage.</li> <li>• Do not turn the phase advance capacitor on or off.</li> <li>• Insert a AC reactor on the input side.</li> <li>• Increase the deceleration time.</li> <li>• Set the time suited to the load inertia.</li> <li>• Check the regenerative braking use rate once again.</li> </ul>
		CT	✓	CT error	B	<ul style="list-style-type: none"> <li>• Is the CT normal?</li> </ul>	<ul style="list-style-type: none"> <li>• Replace the CT.</li> </ul>
		USP	✓	USP error	B	<ul style="list-style-type: none"> <li>• Is power turned on after the USP is selected?</li> <li>• Is the operation command issued when an error occurs in the power source?</li> </ul>	<ul style="list-style-type: none"> <li>• Select the USP after power is turned on.</li> <li>• Check the power supply capacity.</li> </ul>
		OC. Accel	✓	Overcurrent during motor acceleration	B	<ul style="list-style-type: none"> <li>• Is the motor suddenly accelerated?</li> <li>• Is there an output short-circuit or ground fault?</li> <li>• Is the start or jogging frequency high?</li> <li>• Is the torque boost high?</li> <li>• Is the motor restrained?</li> </ul>	<ul style="list-style-type: none"> <li>• Increase the acceleration time.</li> <li>• Repair the short-circuited or grounded part.</li> <li>• Decrease the start or jogging frequency.</li> <li>• Decrease the torque boost.</li> <li>• Release the restraint of the motor.</li> </ul>
		OC. Decel	✓	Overcurrent during motor deceleration	B	<ul style="list-style-type: none"> <li>• Is the motor suddenly decelerated?</li> <li>• Is there an output short-circuit or ground fault?</li> </ul>	<ul style="list-style-type: none"> <li>• Increase the deceleration time.</li> <li>• Set the time suited to the load inertia.</li> <li>• Repair the short-circuited or grounded part.</li> </ul>
		OC. Drive	✓	Overcurrent during constant speed operation of motor	B	<ul style="list-style-type: none"> <li>• Is the load suddenly changed?</li> <li>• Is there an output short-circuit or ground fault?</li> </ul>	<ul style="list-style-type: none"> <li>• Replace or repair the motor.</li> <li>• Repair the grounded part.</li> </ul>
		Over. L	✓	Inverter overload	B	<ul style="list-style-type: none"> <li>• Is the load heavy?</li> <li>• Is the electronic thermal level correct?</li> </ul>	<ul style="list-style-type: none"> <li>• Decrease the load.</li> <li>• Increase the appropriate motor level. (Note 1)</li> </ul>
		Over. C	✓	Overcurrent immediately after the power is turned on.	B	Is the current sensor or the PC board circuit normal?	Check the current sensor or the PC board detection circuit.
		OH. Fin	✓	High temperature rise <ul style="list-style-type: none"> <li>• Power element cooling fan</li> <li>• Regenerative braking discharge resistor</li> <li>• Rush current limitation resistor</li> </ul>	B	<ul style="list-style-type: none"> <li>• Is the cooling fan running?</li> <li>• Is the inverter air suction or exhaust part closed?</li> <li>• Is the ambient temperature high?</li> <li>• Is the set regenerative braking use rate correct?</li> <li>• Is the electromagnetic contactor of the inverter normal?</li> </ul>	<ul style="list-style-type: none"> <li>• Replace the cooling fan.</li> <li>• Keep the suction or exhaust part unclosed.</li> <li>• Decrease the ambient temperature.</li> <li>• Decrease the set value of BRD%ED.</li> <li>• Replace the electromagnetic contactor of the inverter.</li> </ul>
		CPU	✓	(CPU error)	B	<ul style="list-style-type: none"> <li>• Is a high noise source nearby?</li> <li>• Is the inverter normal?</li> </ul>	<ul style="list-style-type: none"> <li>• Keep the noise source away from the inverter.</li> <li>• Repair the inverter.</li> </ul>
		NG. Op	✓	Incorrect insertion of optional PC board (When used)	B	<ul style="list-style-type: none"> <li>• Is the optional PC board correctly inserted?</li> <li>• Is the contact satisfactory?</li> </ul>	<ul style="list-style-type: none"> <li>• Insert the optional PC board once again.</li> <li>• Replace the optional PC board.</li> </ul>
		Op. ERR	✓	Option error	B	• Malfunction or fault of the PC board	• Check for an error of the optional PC board.
		NG. JOG	✓	Jogging error	B	The commercial supply voltage is switched during jogging.	• Check for a malfunction.

Symptom				Fault cause	Reset method	Check points	Countermeasures
MCB operation	Mg operation	(Note 2) Error display (?ERROR ▨▨▨▨)	Alarm relay				
		UV WAIT	N. A.	Supply voltage error (undervoltage)	A	When the restart function is selected, the supply voltage is dropped up to the undervoltage level.	Repair the power source.
		OL. BRD	✓	The regenerative braking time exceeds the set value of BRD%ED.	B	The regenerative braking resistor which is built in the inverter is used as it is.	<ul style="list-style-type: none"> <li>• Increase the deceleration time.</li> <li>• Increase the operation duty cycle.</li> <li>• Increase the set value of BRD%ED using an external option resistor.</li> </ul>
		EEPROM	✓	Soft memory element (EEPROM) data error	—	<ul style="list-style-type: none"> <li>• How many times is data written a day?</li> <li>• See 6.3(3).</li> <li>• Is the power source turned off during copy operation?</li> </ul>	<ul style="list-style-type: none"> <li>• Use a separate type regenerative braking unit BRD-E.</li> </ul>
		RESTART [ ] s ↑ Numeral	N. A.	This is not a fault. The unit counts the time of IPS-R-T down.	—	<ul style="list-style-type: none"> <li>• This is not a fault.</li> </ul>	—
		R-ERROR SYSTEM	N. A.	RAM error		RAM R/W unmatched error of the digital operation panel	Replace the digital operation panel.
				ROM error		ROM sum check error of the digital operation panel	
				Microcomputer error		Microcomputer malfunction	
		R-ERROR COMM <*>	N. A.	Communication error *1: Prity framing overrun, BCC error, protocol error *2: Time out		<ul style="list-style-type: none"> <li>• A communication error occurs between the digital operation panel and the inverter body.</li> <li>• See 9.3(2)(a).</li> <li>• Is the setting of switch on the back correct?</li> <li>• Is the connection cable broken?</li> <li>• Is a high noise source nearby?</li> </ul>	<ul style="list-style-type: none"> <li>• Press one of the keys on the digital operation panel.</li> <li>• When the key is pressed, the unit returns to the status just prior to the error occurrence.</li> <li>• Replace the cable.</li> <li>• Remove any electrical noise source be separating wires.</li> </ul>
		R-ERROR INV RUN	N. A.	During inverter operation		A copy operation is performed during inverter operation.	<ul style="list-style-type: none"> <li>• Press one of the keys on the digital operation panel.</li> <li>• When the key is pressed, the unit returns to the status just prior to the error occurrence.</li> </ul>
		R-ERROR INV TRIP	✓	Inverter trip		A copy operation is performed in the inverter trip state.	
		R-ERROR INV TYPE	N. A.	Inverter type code unmatched		The inverter type code is not as specified when the copy operation is performed.	
		R-ERROR DATA ROM	N. A.	EEPROM sum check error		An EEPROM sum check error occurs during inverter transfer by the copy unit.	
		R-ERROR RD LOCK	N. A.	—		The copy unit reads data when the read lock is set.	
		R-ERROR COPY ROM	N. A.	—		An unmatched occurs in data comparison of the inverter body after the data is copied.	

Note 1 : See the overload protection of inverter and motor.

(3) Open Phase on the Input Side

This inverter is not provided with an open-phase protection unction on the input side. In case of open-phase, the inverter enters the state indicated below.

(a) 1.5 to 2.5LB2 · LD2

- When little load is applied, the inverter is normally operated, though the ripple current of the main capacity is increased and the life of the main capacity (CB) is extremely shortened.
- When a load is applied, the overcurrent protection function is performed. The resistor RS is overheated and the alarm OH.Fin function may be performed. The converter module (DM) is rarely damaged.

(b) 3.5LB2 · LD2 to 40LB2, 2.5 to 75HB2

Open phase	Model	Error
S or T	3.5 to 5.5LB2 · LF2 25 to 75HB2	Since the relay 84 is not turned on, the resistor RS is overheated, the alarm OH - Fin indicator comes on, and a power failure may be caused
R or S	8 to 40LB 2 8 to 16LF 2	
R	3.5 to 5.5LB2 · LF2 2.5 to 75HB2	Same as (a)
T	8 to 40LB 2 8 to 16LF 2	

(c) The control power supply circuit on the PC board may be damaged. (A circuit consisting of Ro and To)

The inverter is normally operated, though the alarm hold circuit is not operated.

(4) Converter Module Damage

- The unbalance factor of supply voltage is 3% or more.
- The power supply capacity is 10 times or more of the inverter capacity and 500kVA or more.
- The supply voltage is suddenly changed.


Example :

- A plurality of inverters are connected with short bus conductors.
- The phase advance capacitor is turned on or off.


In the above cases, it is recommended to insert a reactor of about 3% (a voltage drop at the rated current) of the supply voltage on the power supply side.

### 8.3 Troubleshooting

- The motor does not run.









Use the variable resistor for operation.



Note 1: Before installing or removing the digital operation panel, turn the inverter off except for a trip.

□ The inverter does not operate.

Phenomena	Check points	Countermeasures
The inverter does not operate.	Is the  key on the digital operation panel pressed in the Terminal mode?	Stop the operation command from the "Terminal", and then enter the operation command once again. (Or, specify "Validity" or "Invalidity" by selecting SWITCH 2.)
	Is the DB command entered to the optional PC board (A-OP-PCB) ?	Release the DB command, and then enter the operation command.
	Is the FRS command entered?	Release the FRS command, and then enter the operation command.
	Is the frequency set to 0 ?	Set the frequency to the desired one.
	Does the digital operation panel display the function mode?	Press the  key to select the monitor mode.
	Is the inverter tripped?	Reset the inverter.
	Is the speed command entered between O and L or OI and L when the frequency commanding method (F-SET-M) is "Terminal"?	Check the speed command circuit once again.
	Is a command entered to the multistage speed input terminals CF 1 and CF 2, or are Speed 1 to Speed 3 set to 0 Hz?	Set Speed 1 ~ Speed 3 to the desired frequency, or release the command to CF 1 and CF 2.
	Is the RS command entered?	Release the RS command.
	Is a command externally entered with the internal command (Remote) mode selected, or is a command entered from the digital operation panel with the external command (Terminal) selected?	Check the operation mode. (Enter the operation command in the preset mode.)
	<ul style="list-style-type: none"> <li>• Are the  and  keys simultaneously pressed in the internal command (Remote) mode?</li> <li>• Are the FW and RV terminals simultaneously turned on in the external command (Terminal) mode?</li> </ul>	Be sure to allow the forward or reverse operation to be performed.
	<ul style="list-style-type: none"> <li>• Is the set frequency less than the minimum frequency?</li> </ul>	Set the frequency to more than the minimum frequency.
	Is the operation command, which is not accepted in the forward or reverse command mode, entered in such a mode?	Check the operation mode.  See F-28⑤
The jogging operation is not performed. When the expansion multistage speed mode is selected, the jogging operation is not performed but the multistage speed operation is done. The set value is max. 9.9 Hz.	<ul style="list-style-type: none"> <li>• Is the frequency set?</li> <li>• Are the multistage speed terminals CF 1 and CF 2 turned on?</li> </ul>	<ul style="list-style-type: none"> <li>• Set the frequency to 0.</li> <li>• Do not turn CF 1 and CF 2 ON.</li> </ul>
	<ul style="list-style-type: none"> <li>• Is the relationship between the jogging frequency setting (Fj) and the minimum frequency setting (Fmin) that <math>F_j &lt; F_{min}</math>?</li> </ul>	Set the relationship to $F_j \geq F_{min}$
The motor does not run smoothly and the number of revolutions does not increase.	<ul style="list-style-type: none"> <li>• Motor capacity [ ] kw and number of pole [ ] P are set correctly?</li> <li>• Is the motor current pulsated?</li> <li>• Is the motor no-load current pulsated and increased?</li> </ul>	<ul style="list-style-type: none"> <li>• Set the correct data to the motor. See F-00</li> <li>• Remove the cause of the load torque pulsation.</li> <li>• Decrease the carrier frequency of the inverter.  See F-41.</li> </ul>

□ When the rotational speed of the motor is high, check the number of poles of the motor and the set frequency.




# 9. HANDLING THE DIGITAL OPERATION PANEL

This chapter explains how to operate the inverter using an optional digital operation panel (copy unit). A remote operator (DOP) and a copy unit (DRW) can be used for inverter operation. This operation panel can be incorporated into inverter body or installed separately.

## 9.1 Name of Each Unit of the Digital Operation Panel and Description









(Example of copy unit(DRW))



Classification	Key	Key name	Description
Mode selection	モニタ MON	Monitor	This key selects the monitor mode.
	機能 FUN	Function	This key selects the function mode. Function 1 mode : This mode selects the function name, and sets or changes data. Function 2 mode : This mode sets or changes data. Function 3 mode : This mode sets or changes data.
	記憶 STR	Storage	This key stores the data which is set by the function mode.
Data setting, change	▶	Cursor movement	This key moves the cursor to the position of the data to be set or changed.
	▲	UP	This key sets or change data. • Numeric ( 0 , 1 , 2 , ... , 8 , 9 ) : The ▲ key increments 1 and the ▼ key decrements 1. When 9 is increased to 0, a carry occurs. • Character : The ▲ key selects the next character (for example, from A to B) and the ▼ key selects the previous character (for example, from B to A). • Code : The ▲ key selects the next code (for example, from Remote to Terminal) and the ▼ key selects the previous code (for example, from Terminal to Remote). • Mode : The ▲ key selects the next mode (for example, from F-00 CONTROL to F-01 ACCEL-1) and the ▼ key selects the previous code (for example, from F-01 ACCEL-1 to F-00 CONTROL). (Holding one key pressed changes data continuously.)
	▼	DOWN	
Operation Stop	正転運転 FWD RUN	Forward operation	This key directs forward operation.
	逆転運転 REV RUN	Reverse operation	This key directs reverse operation.
	停止 STOP	Stop	This key stops operation.

## 9.2 Return to Initial Settings (Status Before Delivery)

This section explains how to restore the initial setting.

Operation procedure	Description
<div style="border: 1px solid black; padding: 5px; text-align: center;">Power ON</div>	<p>When power is turned on, the display before power is turned off appears.</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <code>FS 000.0 000.0 Hz</code> </div>
<div style="border: 1px solid black; padding: 5px; text-align: center;">DIP switch selection</div>	<p>Set the second DIP switch (from the right end) of the PC board to ON.</p> <div style="text-align: center;">  <p>Set this DIP switch to ON. <span style="float: right;">See Figure 16</span></p> </div>
<div style="border: 1px solid black; padding: 5px; text-align: center;">Function mode switch selection 3 selection</div>	<p>Press the <code>FUN</code> key once, the  key 24 times, and the <code>FUN</code> key once.</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <code>SWITCH 3 SLCT SPD</code> </div>
<div style="border: 1px solid black; padding: 5px; text-align: center;">Standard value selection</div>	<p>Move the cursor to the S position by the  key, and press the  key three times.</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <code>SWITCH 3 STDT RST</code> </div> <p style="text-align: center;">Cursor movement</p>
<div style="border: 1px solid black; padding: 5px; text-align: center;">Reset command</div>	<p>Move the cursor to the R position by the  key, and press the  key.</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <code>SWITCH 3 * STDT SET</code> </div> <p style="text-align: center;">Cursor movement</p>
<div style="border: 1px solid black; padding: 5px; text-align: center;">Reset command</div>	<p>Press the <code>STR</code> key to store the standard value.</p>
<div style="border: 1px solid black; padding: 5px; text-align: center;">Reset command</div>	<p>Reset the RS terminal. (Close the switch.)</p> <div style="text-align: center;">  </div>
<div style="border: 1px solid black; padding: 5px; text-align: center;">Release the DIP switch selection.</div>	<p>Set the second DIP switch to OFF.</p> <div style="text-align: center;">  <p>Set this DIP switch to OFF.</p> </div> <p>Note : When the second switch(soft lock)from the left end of the DIP switch is set to the ON position(see page 93), the initial setting can not be restored.</p>




Note:In initial setting the inverter with remot operator, frequency setting and operation command change from Remote(Remote operator side)to Terminal(terminal side)

### 9.3 Monitor Mode

#### (1) Monitor Mode List

The monitor mode initial display contents, standard set values, and change range are as follows :

- ✓ : The set values can be changed when the inverter is in operation.
- N.A. : No set value can be changed during operation.
- : Only display

Se- quence	Monitor name	Initial display contents	Standard set value	Changes	Data setting, changes	Remarks		
1	Frequency setting, output frequency		000.0	000.0- 375.0	✓	<ul style="list-style-type: none"> <li>• ① designates a set value.</li> <li>• ② designates an output value.</li> <li>• [ ] is displayed when the operation command is turned on. F : Forward R : Reverse</li> <li>• The multistage speed is displayed when the terminal is turned on.</li> <li>• When the multistage speed is selected, the jogging is one of the multistage speed, and the inverter starts or stops soft.</li> </ul>		
	Multistage speed setting, output frequency	1 S 0 0 0 . 0 [ ] 0 0 0 . 0 H z						
		2 S 0 0 0 . 0 [ ] 0 0 0 . 0 H z						
		3 S 0 0 0 . 0 [ ] 0 0 0 . 0 H z						
		4 S 0 0 0 . 0 [ ] 0 0 0 . 0 H z						
		Expansion multistage	5 S 0 0 0 . 0 [ ] 0 0 0 . 0 H z					
			6 S 0 0 0 . 0 [ ] 0 0 0 . 0 H z					
	Jogging frequency setting, output frequency	J G 0 0 1 . 0 [ ] 0 0 0 . 0 H z	1.0	0.0, 0.5- 9.9				
	Process stepping setting, output frequency		000.0	000.0- 375.0	N.A.		<ul style="list-style-type: none"> <li>• ① designates a set value.</li> <li>• ② designates an output value.</li> <li>• [ ] is displayed when the operation command is turned on. F : Forward R : Reverse</li> <li>• The process stepping is displayed when the terminal is turned on.</li> <li>• The set frequency can be changed.</li> </ul>	
		2 P 0 0 0 . 0 [ ] 0 0 0 . 0 H z						
3 P 0 0 0 . 0 [ ] 0 0 0 . 0 H z								
0 P 0 0 0 . 0 0 0 0 . 0 H z								
2	Frequency commanding method	F - S E T - M T e r m i n a l	Terminal	Remote, Terminal or Option - b	N.A.	Remote : A command from the remote operator Terminal : Inverter terminal com- mand		
3	Operation commanding method	F / R - S W T e r m i n a l	Terminal Note 1	Remote, Terminal or Option - b	N.A.	Option - b : A command from the A - S C - O C B		
4	Motor rotational speed displs	R P M 4 P 0 0 0 0 0 R P M	4	2-48	✓	The periodic speed is displayed.		
5	Frequency converted value display	/ H z 0 0 . 0 0 0 0 0 0 . 0 0	00.0	00.0- 99.9	✓	Optional values per Hz are displayed.		
6	Output current display		-	3.0-260	✓	① designates the rated current of the inverter and ② designates the output current.		

The monitor mode initial display contents, standard set values, and change range are as follows :

- ✓ : The set values can be changed when the inverter is in operation.
- N.A. : No set value can be changed during operation.
- : Only display

Se- quence	Monitor name	Initial display contents	Standard set value	Changes	Data setting, changes	Remarks
7	Manual torque boost adjustment	CONTROL VF V- Boost Code<031>	031	000-099	✓	
		CONTROL SLV 1 or CONTROL SLV 2 V- Boost Code<110>	110	000-150	✓	
8	Output voltage gain adjustment	V - G a i n            1 0 0 %	100	100-50	✓	
9	Jogging frequency setting	J o g g i n g            0 1 . 0 H z	1.0	0.0, 0.5-9.9	✓	
10	Set parameter check	C H E C K            +	-	-	-	OK designates that the parameters are not contradictory to each other. When the parameters are contradictory to each other, the parameter contents are displayed.
		C H E C K            -            O K				
11	Forced rewriting of set parameters	F O R C E   S E T   +	-	-	-	This mode is valid when the parameters are contradictory to each other. The contents of a parameter forcibly rewritten are displayed.
		? W A R N            * * - * *				
12	Terminal monitor	T E R M I N L    0 0 0 0 0 0 0 0 ↑ ↑ ↑ ↑ ↑ ↑ ↑ ↑ FW            ↑ RV            ↑ JG            ↑ CF 1          ↑ CF 2          ↑ FRS          ↑ 2CH          ↑ USP          ↑	-	-	-	1 is displayed when a terminal input signal is low or 0 is displayed when it is high.
13	Fault display	#	-	-	-	# designates the normal operation. When a fault occurs, the fault contents are displayed in a priority base.
		? E R R O R    O v e r   V .				
14	Fault trace display	? E R R   C O U N T    0 0 0	-	-	-	The contents of the last three faults including the current one are displayed. (Current and frequency when the fault occurs)

Note 1 : The inverter with remote operator (LD2, LF2) is Remote mode.


(2) Monitor Mode Operation

(a) Before using the remote operator(DOP)and copy unit(DRW)

When the HFC-VWA inverter is used, change the switches on the back as follows:

1: ON→OFF, 2: OFF→ON.

Unless the switches are changed, no operation can be performed.



(b) Monitor mode operation

When the inverter is turned on, the monitor mode FS000.0..... is displayed.

When the following is displayed when power is turned off before turning it on, the display appears once again.

- Frequency setting, multistage speed setting, and jogging frequency
- Motor speed, frequency converted value, and output current
- Jogging frequency setting









**Monitor mode screen scrolling method and cursor moving method**




Note : When the dip switch is ON(soft lock), the cursor will not be moved.  
(For details on soft lock, see page 93.)

Scrolling of monitor mode screen		Cursor movement	
Key operation		Key operation	The cursor moves in one direction, from left to right.
Advance to next mode	Return to Previous mode	Display	Display
<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">モニタ MON</div>		<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">FS000.0 000.0Hz</div>	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">FS000.0 000.0Hz</div>
<div style="display: flex; justify-content: space-around; width: 100%;"> <div style="border: 1px solid black; padding: 2px; width: 45%;">モニタ MON</div> <div style="border: 1px solid black; padding: 2px; width: 45%; text-align: center;">▲</div> </div>	▼	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">F-SET-M Terminal</div>	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">FS000.0 000.0Hz</div>
<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">F/R-SW Terminal</div>	▲	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">#1, 2, 3,</div>	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">FS000.0 000.0Hz</div>
<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">モニタ MON</div>	▼	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">FS000.0 000.0Hz</div>	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">FS000.0 000.0Hz</div>
<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">モニタ MON</div>	▼	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">FS000.0 000.0Hz</div>	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">FS000.0 000.0Hz</div>
<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">モニタ MON</div>	▼	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">FS000.0 000.0Hz</div>	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">FS000.0 000.0Hz</div>
<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">モニタ MON</div>	▼	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">FS000.0 000.0Hz</div>	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">FS000.0 000.0Hz</div>
<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">モニタ MON</div>	▼	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">FS000.0 000.0Hz</div>	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">FS000.0 000.0Hz</div>
<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">モニタ MON</div>	▼	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">FS000.0 000.0Hz</div>	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">FS000.0 000.0Hz</div>






















(3) Relationship Between Monitor Mode Set or Changed Contents and Output Signal



Display sequence	Monitor name	Key operation	Display	Relationship between contents and I/O signal																																																												
1	Frequency setting command, Output frequency display	Mode selection 	Initial display 	<ul style="list-style-type: none"> <li>Frequency setting when the Remote mode is selected end frequency monitor</li> <li>When the Remote mode is not selected, <span style="border: 1px solid black; padding: 2px;">FS.....</span> cannot be set. (When the Terminal mode is selected, the display appears.)</li> </ul> The frequency is set in the ① area. When the operation command is entered, the output frequency is increased to the preset frequency. To increase or decrease the frequency during operation, change the frequency in the ① area. F is displayed in the ② area when the forward operation is selected or R is displayed when the reverse operation is selected. The output frequency is displayed in the ③.																																																												
		Data setting 																																																														
		Operation command 																																																														
			Multistage speed set (Initial display 0)  <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> <p>1 st stage: 1</p> <p>2 nd stage: 2</p> <p>3 rd stage: 3</p> <p>4 th stage: 4</p> <p>5 th stage: 5</p> <p>6 th stage: 6</p> <p>7 th stage: JG</p> <p>8 th stage: FS</p> </div> <div> <p>No expansion multistage speed is selected.</p> <p>The multistage speed is selected.</p> </div> </div> Notes: 1. When SW 1 and SW 2 or SWJ is turned on in the monitor mode, the multistage speed displayed above is available. 2. Values, which are set in the monitor mode, can be changed when the inverter is in operation. 3. Values can also be set in the function mode. When the monitor mode is selected after setting, the set values are displayed.																																																													
			• Multistage speed  <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th></th> <th>SW 1</th> <th>SW 2</th> <th>:- OFF</th> </tr> </thead> <tbody> <tr> <td>1 st stage</td> <td>ON</td> <td>—</td> <td></td> </tr> <tr> <td>2 nd stage</td> <td>—</td> <td>ON</td> <td></td> </tr> <tr> <td>3 rd stage</td> <td>ON</td> <td>ON</td> <td></td> </tr> </tbody> </table> • Multistage speed  <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th></th> <th>SW 1</th> <th>SW 2</th> <th>SWJ</th> <th>:- OFF</th> </tr> </thead> <tbody> <tr> <td>1 st stage</td> <td>ON</td> <td>—</td> <td>—</td> <td></td> </tr> <tr> <td>2 nd stage</td> <td>—</td> <td>ON</td> <td>—</td> <td></td> </tr> <tr> <td>3 rd stage</td> <td>ON</td> <td>ON</td> <td>—</td> <td></td> </tr> <tr> <td>4 th stage</td> <td>ON</td> <td>—</td> <td>ON</td> <td></td> </tr> <tr> <td>5 th stage</td> <td>—</td> <td>ON</td> <td>ON</td> <td></td> </tr> <tr> <td>6 th stage</td> <td>ON</td> <td>ON</td> <td>ON</td> <td></td> </tr> <tr> <td>7 th stage</td> <td>—</td> <td>—</td> <td>ON</td> <td></td> </tr> <tr> <td>8 th stage</td> <td>—</td> <td>—</td> <td>—</td> <td></td> </tr> </tbody> </table> <p style="margin-left: 20px;">→ Set by FS</p>		SW 1	SW 2	:- OFF	1 st stage	ON	—		2 nd stage	—	ON		3 rd stage	ON	ON			SW 1	SW 2	SWJ	:- OFF	1 st stage	ON	—	—		2 nd stage	—	ON	—		3 rd stage	ON	ON	—		4 th stage	ON	—	ON		5 th stage	—	ON	ON		6 th stage	ON	ON	ON		7 th stage	—	—	ON		8 th stage	—	—	—	
	SW 1	SW 2	:- OFF																																																													
1 st stage	ON	—																																																														
2 nd stage	—	ON																																																														
3 rd stage	ON	ON																																																														
	SW 1	SW 2	SWJ	:- OFF																																																												
1 st stage	ON	—	—																																																													
2 nd stage	—	ON	—																																																													
3 rd stage	ON	ON	—																																																													
4 th stage	ON	—	ON																																																													
5 th stage	—	ON	ON																																																													
6 th stage	ON	ON	ON																																																													
7 th stage	—	—	ON																																																													
8 th stage	—	—	—																																																													















Display sequence	Monitor name	Key operation	Display	Relationship between contents and I/O signal
			<div style="border: 1px solid black; padding: 5px; display: inline-block;">1 S 0 1 0 . 0 0 0 0 . 0 H z</div> <p>When setting the multistage speed beforehand, it is convenient to use the function mode. When data is set in the function mode and then changed in the monitor mode, the data, which is set in the function mode, is simultaneously changed.</p>	<p>Note 1: Use SWITCH 2 for expansion multistage speed selection. (See page 82)</p> <p>Note 2: When the expansion multistage speed is selected, the jogging terminal(JG)command is a multistage speed function instead of a jogging function.</p> <p>For this reason, remember the following :</p> <ul style="list-style-type: none"> <li>• For acceleration, the inverter starts or stops soft.</li> <li>• The set value ranges from 0.5 to 9.9 Hz.</li> <li>• The initial value is 1 Hz.</li> <li>• A frequency jump cannot be set.</li> </ul> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;">See the section of multistage speed in the function mode(page 71).</div>
2	Frequency commanding method	<p>Mode selection</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;">モニタ MON</div> <div style="display: inline-block; vertical-align: middle;">▲ ▼</div>	<p>Initial display</p> <div style="border: 1px solid black; padding: 5px; display: inline-block;">F - S E T - M T e r m i n a l</div>	<p>Input signal</p> <p>Frequency setting command (O: Voltage input OI: Current input)</p> <p>VRO specification 2 W 500Ω 1 W 1KΩ, 2KΩ</p>  <p>Set the frequency as specified below.</p> <p>(a) By variable resistor connect a variable resistor VRO between H, O, and L on the PC board. Input impedance 30KΩ</p> <p>(b) By an externally preset signal</p>
		<p>Dip switch</p> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="margin-bottom: 10px;"> <p>5V</p> <div style="border: 1px solid black; padding: 2px;"> <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> </div> <p>10V (At 0 to 10 VDC)</p> </div> <div> <p>5V</p> <div style="border: 1px solid black; padding: 2px;"> <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> </div> <p>10V (At 0 or 5 VDC)</p> </div> </div> <p>The dip switch can be seen on the PC board when the terminal cover is removed.</p>	<p>Voltage setting input impedance</p> <p>0 to 10 V:30 KΩ 0 to 5 V:15KΩ</p>  <p>Note : Do not apply a voltage of 12 VDC or more between O and L.</p> <p>Current setting Input impedance: 250Ω</p>  <p>Note:Connect AT and L to make OI input valid.</p>	
	<p>Data setting</p> <div style="display: inline-block; vertical-align: middle;">▶</div> <div style="display: inline-block; vertical-align: middle;">▲ ▼</div>	<div style="border: 1px solid black; padding: 5px; display: inline-block;">F - S E T - M R e m o t e</div>	<div style="border: 1px solid black; padding: 5px; display: inline-block;">F - S E T - M O p t i o n - b</div>	<p>Select when the Remote(the digital operation unit)mode is used for frequency setting FS. Select when the A-SC-PCB(Optional)is used for frequency setting FS.</p>


































Display sequence	Monitor name	Key operation	Display	Relationship between contents and I/O signal																												
3	Operation commanding method	Modo selection   	Initial display (without remote operator) <div style="border: 1px solid black; padding: 2px; display: inline-block;">F/R-SW Terminal</div> Initial display (with remote operator) <div style="border: 1px solid black; padding: 2px; display: inline-block;">F/R-SW Remote</div>	Forward operation command (FW) Reverse operation command (RV)  																												
		Data setting    	<div style="border: 1px solid black; padding: 2px; display: inline-block;">F/R-SW Remote</div> <div style="border: 1px solid black; padding: 2px; display: inline-block;">F/R-SW Option-b</div>	Note: To stop the inverter, turn SWF (SWR) OFF or press the  key on the digital operation panel. When it is undesirable to stop the inverter by the  key on the digital operation panel, select "Valid" or "Invalid" by SWITCH 2 (see page 80). The standard setting is "Valid" or "STOP ON"; that is, the inverter stops. When stopping the inverter in the Remote mode and restarting it in the Terminal mode, turn SWF (SWR) off beforehand. Otherwise, the inverter cannot be restarted.																												
4	Motor speed display	Mode selection   	Initial display <div style="border: 1px solid black; padding: 2px; display: inline-block;">RPM 4P 00000 rpm</div> 	When the number of poles of the motor is displayed in the ① area, the number of synchronization revolutions of the motor in operation is displayed in the ② area.  Motor pole count code																												
		Data setting    	<div style="border: 1px solid black; padding: 2px; display: inline-block;">RPM 4P 01500 rpm</div>	<table border="1" style="width: 100%; text-align: center;"> <tr> <td>Display sequence</td> <td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td><td>11</td><td>12</td><td>13</td><td>14</td> </tr> <tr> <td>Number of poles</td> <td>2</td><td>4</td><td>6</td><td>8</td><td>10</td><td>12</td><td>14</td><td>16</td><td>18</td><td>20</td><td>24</td><td>32</td><td>36</td><td>48</td> </tr> </table>	Display sequence	1	2	3	4	5	6	7	8	9	10	11	12	13	14	Number of poles	2	4	6	8	10	12	14	16	18	20	24	32
Display sequence	1	2	3	4	5	6	7	8	9	10	11	12	13	14																		
Number of poles	2	4	6	8	10	12	14	16	18	20	24	32	36	48																		

Display sequence	Monitor name	Key operation	Display	Relationship between contents and I/O signal																																	
5	Frequency conversion display	Mode selection モニタ MON ▲ ▼	Initial display Hz 00.0 00000.0 ① ②	Optional values per Hz are displayed in the ① area. The display area ② displays the product of the output frequency and the value in the ① area.  $② = ① \times \text{output frequency}$																																	
		Data setting ▶ ▲ ▼	Hz 33.3 02000.0																																		
6	Output current display	Mode selection モニタ MON ▲ ▼	Initial display I f --- A I m 000.0 % ① ②	When the rated current is not displayed in the ① area, the rate of the rated current to the rated current of the inverter is displayed in the ② area in %. When the inverter rated current given in the table below is entered in the ① area, the effective value (A) of inverter output current is displayed in the ① area.																																	
		Data setting ▶ ▲ ▼	I f 5.0 A I m 004.5 A																																		
		-	I f --- A I m 090.0 %																																		
Inverter rated current code																																					
		<table border="1"> <thead> <tr> <th>Display sequence</th> <th>1</th> <th>2</th> <th>3</th> <th>4</th> <th>5</th> <th>6</th> <th>7</th> <th>8</th> <th>9</th> <th>10</th> <th>11</th> <th>12</th> <th>13</th> <th>14</th> </tr> </thead> <tbody> <tr> <td>Inverter rated current</td> <td>3.0</td> <td>3.8</td> <td>5.0</td> <td>5.3</td> <td>7.5</td> <td>8.6</td> <td>10.5</td> <td>13.0</td> <td>16.0</td> <td>16.5</td> <td>23</td> <td>24</td> <td>32</td> <td>46</td> </tr> </tbody> </table>	Display sequence	1	2	3	4	5	6	7	8	9	10	11	12	13	14	Inverter rated current	3.0	3.8	5.0	5.3	7.5	8.6	10.5	13.0	16.0	16.5	23	24	32	46					
Display sequence	1	2	3	4	5	6	7	8	9	10	11	12	13	14																							
Inverter rated current	3.0	3.8	5.0	5.3	7.5	8.6	10.5	13.0	16.0	16.5	23	24	32	46																							
		<table border="1"> <tbody> <tr> <td>15</td> <td>16</td> <td>17</td> <td>18</td> <td>19</td> <td>20</td> <td>21</td> <td>22</td> <td>23</td> <td>24</td> <td>25</td> <td>26</td> <td>27</td> <td>28</td> <td>29</td> </tr> <tr> <td>48</td> <td>58</td> <td>64</td> <td>75</td> <td>90</td> <td>95</td> <td>110</td> <td>121</td> <td>145</td> <td>149</td> <td>176</td> <td>182</td> <td>217</td> <td>220</td> <td>260</td> </tr> </tbody> </table>	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	48	58	64	75	90	95	110	121	145	149	176	182	217	220	260					
15	16	17	18	19	20	21	22	23	24	25	26	27	28	29																							
48	58	64	75	90	95	110	121	145	149	176	182	217	220	260																							

Display sequence	Monitor name	Key operation	Display	Relationship between contents and I/O signal
7	Manual torque boost adjustment	Mode selection モータ MON ▲ 2 ▼ 3	Initial display (at CONTROL VF) V - B o o s t C o d e < 0 3 1 >	The output voltage at the time of start or in the low frequency band is increased for boost adjustment.  
		Data setting ▶ 1 ▲ 2 ▼ 3	V - B o o s t C o d e < 0 9 9 >	
		Mode selection モータ MON ▲ 2 ▼ 3	Initial display (at CONTROL SLV 1 or SLV 2) V - B o o s t C o d e < 3 1 >	The output voltage at the time of start or in the low frequency band (below 5 Hz) is increased for boost adjustment.  
		Data setting ▶ 1 ▲ 2 ▼ 3	V - B o o s t C o d e < 9 9 >	

Display sequence	Monitor name	Key operation	Display	Relationship between contents and I/O signal
8	Output voltage gain adjustment	Mode selection モニタ MON  	Initial display <div style="border: 1px solid black; padding: 2px; display: inline-block;">V - G a i n                    1 0 0 %</div>	The gain of the output voltage for the frequency is changed.  
		Data setting   	<div style="border: 1px solid black; padding: 2px; display: inline-block;">V - G a i n                    5 0 %</div>	
9	Jogging frequency setting	Mode selection モニタ MON  	Initial display <div style="border: 1px solid black; padding: 2px; display: inline-block;">J o g g i n g                    0 1 . 0 H z</div>	<ul style="list-style-type: none"> <li>• The jogging frequency is set.</li> <li>• Jogging is a direct operation, causing a trip. Set the frequency to less than 5 Hz.</li> <li>• When the switch is turned off, a free run will result.</li> </ul>  <p>Jogging operation when the operation command is externally performed</p>  <p>Note 1 : The jogging operation is not performed in the following cases:            1) The multistage speed is selected and JG is one of the speeds.            2) A frequency other than the jogging frequency is set.            3) The terminals CF 1 and CF 2 for multistage speed are turned on.            4) The preset minimum frequency(Fmin)is higher than the jogging frequency.            5) The process stepping mode is selected.</p> <p>Note 2 : The optional remote operator or copy unit is not available for jogging.(Jogging is not accepted and the normal operation is selected.)</p>
		Data setting   	<div style="border: 1px solid black; padding: 2px; display: inline-block;">J o g g i n g                    0 5 . 0 H z</div>	

Display sequence	Monitor name	Key operation	Display	Relationship between contents and I/O signal
10	Set parameter check	Mode selection   	Initial display 	<ul style="list-style-type: none"> <li>• A contradiction between the parameters for setting the frequency is checked, and contradictory parameters are displayed.</li> <li>• For detailed errors, refer to Appendix Table 1.</li> </ul>
		Data setting  	Normal   Error 	
11	Preset parameter forced rewriting	Mode selection   	Initial display 	<ul style="list-style-type: none"> <li>• A contradictory frequency parameter is forcibly rewritten so as to eliminate the contradiction.</li> <li>• For rewritten data, refer to Appendix Table 2.</li> </ul>
		Data setting  		
12	Terminal monitor	Mode selection 	Initial display 	<ul style="list-style-type: none"> <li>• 1 is displayed when a terminal input signal is low or 0 is displayed when it is high.</li> <li>• The relationship between each terminal and the display is as follows:</li> </ul> 

Display sequence	Monitor name	Key operation	Display	Relationship between contents and I/O signal																									
13	Fault display	Mode selection 	Initial display <div style="border: 1px solid black; padding: 2px; width: fit-content;">#</div>	<ul style="list-style-type: none"> <li>A symbol # designates the normal operation.</li> <li>When the inverter fails, the fault display automatically appears in a priority basis.</li> <li>For detailed display contents, see Table 4 on page 38.</li> </ul>																									
			Fault <div style="border: 1px solid black; padding: 2px; width: fit-content;">? ERROR Over. V</div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px; text-align: center;">             When a fault occurs, a fault signal is outputted simultaneously with fault display.           </div> <div style="margin-top: 10px;"> <p>Output circuit</p>  <p>Contact specification</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Power supply</th> <th>Operation status</th> <th>AL<sub>0</sub>-AL<sub>1</sub></th> <th>AL<sub>0</sub>-AL<sub>2</sub></th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Normal</td> <td>open</td> <td>closed</td> </tr> <tr> <td>ON</td> <td>Abnormal</td> <td>closed</td> <td>open</td> </tr> <tr> <td>OFF</td> <td>-</td> <td>open</td> <td>closed</td> </tr> </tbody> </table> <table border="1" style="margin-left: auto; margin-right: auto; width: 100%;"> <thead> <tr> <th colspan="2">max.</th> <th colspan="2">min.</th> </tr> </thead> <tbody> <tr> <td colspan="2">AC250V, 2.5A(load R)0.2A(cosφ=0.4)</td> <td colspan="2">AC100V, 10mA</td> </tr> <tr> <td colspan="2">DC 30V, 3.0A(load R)0.7A(cosφ=0.4)</td> <td colspan="2">DC 5V, 100mA</td> </tr> </tbody> </table> </div>		Power supply	Operation status	AL <sub>0</sub> -AL <sub>1</sub>	AL <sub>0</sub> -AL <sub>2</sub>	ON	Normal	open	closed	ON	Abnormal	closed	open	OFF	-	open	closed	max.		min.		AC250V, 2.5A(load R)0.2A(cosφ=0.4)		AC100V, 10mA		DC 30V, 3.0A(load R)0.7A(cosφ=0.4)
Power supply	Operation status	AL <sub>0</sub> -AL <sub>1</sub>	AL <sub>0</sub> -AL <sub>2</sub>																										
ON	Normal	open	closed																										
ON	Abnormal	closed	open																										
OFF	-	open	closed																										
max.		min.																											
AC250V, 2.5A(load R)0.2A(cosφ=0.4)		AC100V, 10mA																											
DC 30V, 3.0A(load R)0.7A(cosφ=0.4)		DC 5V, 100mA																											
14	Fault trace display	          	<div style="border: 1px solid black; padding: 2px; width: fit-content;">#</div> <p>A fault occurs.</p> <div style="border: 1px solid black; padding: 2px; width: fit-content;">? ERROR OC. Accel</div> <div style="border: 1px solid black; padding: 2px; width: fit-content;">? ERR COUNT 001</div> <div style="border: 1px solid black; padding: 2px; width: fit-content;">? ERR COUNT 001</div> <div style="border: 1px solid black; padding: 2px; width: fit-content;">? ER1 OC. Accel</div> <div style="border: 1px solid black; padding: 2px; width: fit-content;">? ER2</div> <div style="border: 1px solid black; padding: 2px; width: fit-content;">? ER3</div> <div style="border: 1px solid black; padding: 2px; width: fit-content;">? ER1 OC. Accel</div> <div style="border: 1px solid black; padding: 2px; width: fit-content;">? ER1 OC. Accel</div> <div style="border: 1px solid black; padding: 2px; width: fit-content;">? ER1 F010.0Hz</div> <div style="border: 1px solid black; padding: 2px; width: fit-content;">? ER1 If 220.0%</div> <div style="border: 1px solid black; padding: 2px; width: fit-content;">? ER1 OC. Accel</div> <div style="border: 1px solid black; padding: 2px; width: fit-content;">? ERROR OC. Accel</div>	<ul style="list-style-type: none"> <li>The contents of the last three faults including the current line are displayed.</li> <li>When no fault occurs, # is displayed.</li> </ul> <p>Display contents</p> <ul style="list-style-type: none"> <li>Fault contents</li> <li>Current when the fault occurs: If(Note)</li> <li>Frequency when the fault occurs:F</li> </ul> <p>Note : The current If at fault occurrence is a reference value. It may differ from the actual value.</p>																									

## 9.4 Function Mode

### (1) Function Mode List

The function 1 mode selects a function name. (No data can be set or changed in this mode).

The function 2 mode sets or changes data. The function 3 mode sets the F-OOV/f pattern and selects the F-10 multistage speed or process stepping mode.

The following table gives the initial display contents, standard settings, and change range.



Display sequence	Function name	Function 1 mode	Display contents	Function 2 mode
1	V/f pattern setting	<u>F</u> -00	CONTROL	<u>C</u> ONTROL
2	Acceleration time setting	<u>F</u> -01	ACCEL-1	<u>A</u> CCEL-1
3	Deceleration time setting	<u>F</u> -02	DECEL-1	<u>D</u> ECEL-1
4	Maximum frequency adjustment	<u>F</u> -03	+Fmax.	+Fmax.
5	Start frequency adjustment	<u>F</u> -04	Fmin.	Fmin.
6	Maximum frequency limiter setting	<u>F</u> -05	H-LIM-F	<u>H</u> -LIM-F
7	Minimum frequency limiter setting	<u>F</u> -06	L-LIM-F	<u>L</u> -LIM-F
8	Jump frequency 1 setting	<u>F</u> -07	JUMP-F1	<u>J</u> UMP-F1
9	Jump frequency 2 setting	<u>F</u> -08	JUMP-F2	<u>J</u> UMP-F2
10	Jump frequency 3 setting	<u>F</u> -09	JUMP-F3	<u>J</u> UMP-F3
11	Multistage speed/process stepping selection	<u>F</u> -10	SEL-S/P	<u>S</u> EL-S/P
12	Start frequency stop time adjustment	<u>F</u> -11	Fstop-T	<u>F</u> stop-T
13	2-stage acceleration time setting	<u>F</u> -18	ACCEL-2	<u>A</u> CCEL-2
14	2-stage deceleration time setting	<u>F</u> -19	DECEL-2	<u>D</u> ECEL-2
15	DC braking frequency adjustment	<u>F</u> -20	F-DCB	<u>F</u> -DCB
16	DC braking power adjustment	<u>F</u> -21	V-DCB	<u>V</u> -DCB
17	DC braking time adjustment	<u>F</u> -22	T-DCB	<u>T</u> -DCB
18	Electronic thermal level adjustment	<u>F</u> -23	E-therm	<u>E</u> -therm
19	Linear-curve acceleration selection	<u>F</u> -24	ACCline	<u>A</u> CCline
20	Linear-curve deceleration selection	<u>F</u> -25	DECLine	<u>D</u> ECLine
21	External frequency setting start	<u>F</u> -26	F-START	<u>F</u> -START
22	External frequency setting end	<u>F</u> -27	F-END	<u>F</u> -END
23	Switch selection 1	<u>F</u> -28	SWITCH1	<u>S</u> WITCH1
24	Switch selection 2	<u>F</u> -29	SWITCH2	<u>S</u> WITCH2
25	Switch selection 3	<u>F</u> -30	SWITCH3	<u>S</u> WITCH3
26	Overload warning level adjustment	<u>F</u> -31	OLalarm	<u>O</u> Lalarm
27	Overload limit constant	<u>F</u> -32	LM. CONS	<u>L</u> M. CONS
28	Allowable instantaneous power failure time setting	<u>F</u> -33	IPS-T	<u>I</u> PS-T
29	Restart standby time setting after instantaneous power failure recovery	<u>F</u> -36	IPS-R-T	<u>I</u> PS-R-T
30	Regenerative braking use rate setting	<u>F</u> -38	BRD-%ED	<u>B</u> RD-%ED
31	Speed arrival signal optional frequency setting	<u>F</u> -39	SPD-ARV	<u>S</u> PD-ARV
32	Simple orientation	<u>F</u> -40	ORIENT	<u>O</u> RIENT
33	Carrier frequency setting	<u>F</u> -41	CARRIER	<u>C</u> ARRIER
34	Parameter setting commanding method	<u>F</u> -42	PARAMSET	<u>P</u> ARAMSET
35	Jump frequency range setting	<u>F</u> -43	JMP-WID	<u>J</u> MP-WID

Initial display contents	Standard setting	Setting, changing range	Remarks
SLV 1	SLV 1	VF, SLV 1, or SLV 2	Standard start torque(VF), high start torque(SLV 1, SLV 2)
0 0 1 0 . 0 S	10	0.1-2999.9(S)	
0 0 1 0 . 0 S	10	0.1-2999.9(S)	
0 0 0 . 0 H Z	0	0-15(Hz)	
0 0 0 . 5 H Z	0.5	0.5-5.0(Hz)	
0 0 0 . 0 H Z	0	0-375(Hz)	Valid for up to the maximum frequency of the selected V/f pattern
0 0 0 . 0 H Z	0	0-375(Hz)	Valid for up to the maximum frequency of the selected V/f pattern
0 0 0 . 0 H Z	0	0-375(Hz)	"
0 0 0 . 0 H Z	0	0-375(Hz)	"
Speed	Speed	Multistage speed or process stepping	Selection of multistage speed(Speed)or process stepping(Process)
0 0 0 . 0 S	0	0-15(S)	
0 0 1 0 . 0 S	10	0.1-2999.9(S)	
0 0 1 0 . 0 S	10	0.1-2999.9(S)	
0 0 0 . 5 H Z	0.5	0.5-375(Hz)	
0 0 0	0	000-020	
0 0 0 . 0 S	0	00-600(S)	
1 0 0 %	100	100-20%	
Linear	Linear	Linear, S-curve, or U-curve	
Linear	Linear	Linear, S-curve, or U-curve	
0 0 0 . 0 H Z	0	0-375(Hz)	
0 0 0 . 0 H Z	0	0-375(Hz)	
DCB ON	See the left		
DB EDG	See the left		
SLCT SPD	See the left	SPD or PRC	
1 0 0 %	100	50-150(%)	Valid only when an optional PC board is used.
1 2 5 % 0 1 . 0	125/01.0	50-150(%) / 0.3-30	
0 0 1 . 0 S	1	0.3-3.0(S)	
0 0 0 1 . 0 S	1	0.3-100.0(S)	
0 1 . 5 %	1.5	0.1-31.0(%)	
1 0 0 %	100	0-100(%)	
f c 0 . 5 H Z	0.5	0.5-9.9(Hz)	Valid only when an optional PC board is used
T w 0 . 0 1 S	0.01	0.01-9.99(S)	(A-OP-PCB).
1 6 k H z	16	8, 10, 12, 16kHz	Standard setting of 33~50kVA units is 12kHz and 60~75kVA depends upon model.
Remote	See the left	Remote or Option-b	
0 . 3 H Z	See the left	0.3-9.9(Hz)	




## (2) Function Mode Operation













- (a) Set or change data in the function mode when the inverter is stopped. (No data can be set or changed when the inverter is in operation.) No data can be set or changed when the inverter is stopped in one of the states indicated below.
- The control circuit terminals RS and L on the PC board are short-circuited and the inverter is stopped.
  - The inverter is tripped and stopped.
- (b) After data is set or changed, be sure to press the **記憶 STR** key. (Otherwise, the data setting or changing operation is made invalid and the previous data is left unchanged.)
- (c) In the function mode, the motor cannot be started running. Press the **モニタ MON** key to select the monitor mode beforehand. (The function mode cannot be referred to during operation.)



(d) Setting and Changing Example

The frequency of the V/f pattern is changed from 60 Hz to 50 Hz.



Operation procedure	Key operation	Display	Description
1		<u>F</u> -0 0      CONTROL	This key selects Function Mode 1 and the V/f pattern setting mode.
2		<u>C</u> ONTROL      SLV 1	This key selects Function Mode 2.
3		<u>S</u> LV 1      F 0 5 0 - 0 5 0	This key selects Function Mode 3.
4		SLV 1      F 0 5 0 - 0 <u>5</u> 0	Press the  key to move the cursor to the position indicated on the left. Note 2
5		SLV 1      *F 0 5 0 - 0 <u>6</u> 0	Press the  key once.
6		SLV 1      *F 0 <u>5</u> 0 - 0 6 0	Press the  key thrice to move the cursor to the position indicated on the left.
7		SLV 1      *F 0 <u>6</u> 0 - 0 6 0	Press the  key once to set 60 Hz.
8		<u>S</u> LV 1      F 0 6 0 - 0 6 0	This key stores the set data. When the data is stored, the * mark is erased.

Note 1 : When a reset signal is entered before power is turned off, the set or changed data is not stored. When turning power off after data is set or changed, do not enter a reset signal simultaneously.

Note 2 : When setting F050-050 to F060-060, set F050-060 first and change it to F060-060.









(e) Motor Capacity and Pole Count  
Operation Example

Motor capacity 3.7 kW → 2.2 kW  
Motor pole count 4 P → 2 P

Operation procedure	Key operation	Display	Description
1		<u>F</u> -00 CONTROL	This key selects Function Mode 1.
2		<u>C</u> ONTROL SLV1	This key selects Function Mode 2.
3		<u>S</u> LV1 F050-050	This key selects Function Mode 3.
4		SLV1 <u>F</u> 050-050	Press the  key once.
5		SLV1 <u>K</u> 3.70k	Press the  key once to display the motor capacity selection screen.
6		SLV1 K 3.7 <u>0</u> k	Press the  key once.
7		SLV1 *K 2.2 <u>0</u> k	Press the  key once to select 2.2 kW.
8		<u>S</u> LV1 K 2.20k	This key stores the set data.
9		SLV1 <u>K</u> 2.20k	Press the  key once.
10		SLV1 <u>P</u> 4p	Press the  key once to display the motor pole count selection screen.
11		SLV1 P <u>4</u> p	Press the  key once.
12		SLV1 *P <u>2</u> p	Press the  key once to set 2 P.
13		<u>S</u> LV1 P 2p	This key stores the set data.


(3) Function mode display, setting, and contents

Data in the cursor-positioned digit of the data setting column can be changed.

Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal
1	(F-00)		Initial setting <div style="border: 1px solid black; padding: 2px; display: inline-block;">_CONTROL SLV 1</div>	High start torque selection ① Selection of high start torque 1 and 2 SLV 1: Hitachi general-purpose motor SLV 2: Exclusive motor ② Selection of frequency, motor capacity, and motor pole count F: Basic frequency and maximum frequency setting K: Motor capacity selection ③ Basic frequency and maximum frequency setting
		機能 FUN	<div style="border: 1px solid black; padding: 2px; display: inline-block;">SLV 1 F 0 6 0 - 0 6 0</div> (* 1) (* 2) 	
		 	Selection to SLV 2 <div style="border: 1px solid black; padding: 2px; display: inline-block;">CONTROL SLV 1</div> <div style="border: 1px solid black; padding: 2px; display: inline-block;">CONTROL SLV 2</div> <div style="border: 1px solid black; padding: 2px; display: inline-block;">SLV 2 F 0 6 0 - 0 6 0</div> (* 1) (* 2) 	
		記憶 STR 機能 FUN	<div style="border: 1px solid black; padding: 2px; display: inline-block;">SLV 1 K 2 . 2 0 K</div> 	
		Data setting	Note1 : Set the motor capacity and pole count according to the motor to be used. When an unmatch occurs, satisfactory characteristics cannot be obtained.  Note2 : When a plurality of motors are to be used, high start torque cannot be used. Select the standard torque beforehand. <span style="border: 1px solid black; padding: 1px;">CONTROL VF</span>	② Selection of motor capacity K: Motor capacity selection ③ Motor capacity display
		 	<div style="border: 1px solid black; padding: 2px; display: inline-block;">SLV 1 P 4 p</div> 	② Selection of motor pole count P: Selection of motor pole count ③ Motor pole count display
			Note 1: When the basic frequency to be used is more than 60 Hz, a special motor should be used instead of a general-purpose motor. Therefore, a different most suitable motor should be used. When the KW indication is the same, the inverter capacity should be increased.	Note 2: When the basic frequency and maximum frequency to be used are more than 120 Hz, set F-28③ to Fmax 360 (see page 75). (An interlock when a high frequency is selected) Note 3: When a high frequency is to be selected, thoroughly check the mechanical strength of the motor and load.

* 1 Basic frequency	50-120	50-360
* 2 Maximum frequency	50-120	50-360

Freely set (Note 2) (Note 3)















Display	0.40K	0.75K	1.50K	2.20K	3.70K	5.50K	7.5K ~75K
Capacity	0.4kW	0.75kW	1.5kW	2.2kW	3.7kW	5.5kW	7.5kW ~75kW


















The most suitable motor is set as standard setting for each inverter.

Example)

inverter	motor capacity	standard setting
3.5SBE	2.2kW	2.20K
5.5 <sup>HBE</sup> <sub>HFE</sub>	4.0kW	4.00K






Display	2 P	4 P	6 P	8 P
Capacity	2 poles	4 poles	6 poles	8 poles

Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal						
1	(F-00)			<p>Note 4: When high frequency is selected, V/f pattern may drop a little bit at around 60 Hz. But this is not abnormal. If compensation is needed, use the followings.</p> <p>Decrease the carrier frequency 16KHz→12→10→8  See (F-41)</p> 						
V/f Pattern setting		   記憶 STR 機能 FUN	Selection of SLV 2 CONTROL <u>SLV 1</u> CONTROL <u>SLV 2</u> <u>SLV 2</u> F 0 6 0 - 0 6 0 ( * 1 ) ( * 2 ) 	High start torque selection ① Selection of high start torque SLV 2: Exclusive motor ② Selection of frequency, motor capacity, and motor pole count F: Basic frequency and maximum frequency setting K: Motor capacity selection P: Selection of motor pole count ③ Basic frequency and maximum frequency setting						
		   記憶 STR	SLV 2 <u>K</u> 2 . 2 k SLV 2 <u>P</u> 4 P 	<table border="1"> <tr> <td>* 1 Basic frequency</td> <td>50-120</td> <td>50-360</td> </tr> <tr> <td>* 2 Maximum frequency</td> <td>50-120</td> <td>50-360</td> </tr> </table>	* 1 Basic frequency	50-120	50-360	* 2 Maximum frequency	50-120	50-360
		* 1 Basic frequency	50-120	50-360						
* 2 Maximum frequency	50-120	50-360								
Note : Set the motor capacity and pole count according to the motor to be used. When an unmatched occurs, satisfactory characteristics cannot be obtained.										
			SLV 2 <u>A</u> 0 0 0 2 2 0  SLV 2 <u>B</u> 0 0 0 3 3 0 SLV 2 <u>C</u> 0 0 0 4 4 0 SLV 2 <u>CD</u> 0 5 Note : When a plurality of motors are to be used, high start torque cannot be used. Select the standard torque beforehand. CONTROL VF	② Selection of motor constant and stabilization A……motor constant B……motor constant C……motor constant CD……motor stabilization gain 00~15 See Section 2.12 Note 1: The copy unit is available for all setting of SLV 2. Note 2: Motor constant > 0 Do not set 0 for motor constant.						

Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal							
1	(F-00)		CONTROL SLV1	Selection of standard start torque ① VF setting VC : Constant torque VP 1: Reduced torque (to the 1.5th power) VP 2: Reduced torque (to the 1.7th power) VP 3: Reduced torque (to the 2nd power) ② Basic frequency and maximum frequency setting							
		  記憶 STR	CONTROL VF								
		機能 FUN	VF-VC 050-050 		<table border="1"> <tr> <td>* 1 Basic frequency</td> <td>50-120</td> <td>50-360</td> </tr> <tr> <td>* 2 Maximum frequency</td> <td>50-120</td> <td>50-360</td> </tr> </table>	* 1 Basic frequency	50-120	50-360	* 2 Maximum frequency	50-120	50-360
		* 1 Basic frequency	50-120		50-360						
		* 2 Maximum frequency	50-120		50-360						
Data setting    記憶 STR	VF-VP1 050-050 VF-VP2 050-050 VF-VP3 050-050	 									
Data setting     記憶 STR	VF-VC 050-050	 									
		機能 FUN 機能 FUN    記憶 STR	Return to SLV1 VF-VC 060-060 E-00 CONTROL CONTROL VF CONTROL VF CONTROL SNSLES CONTROL *SLV1 CONTROL SLV1	<p>Note 1: When basic frequency to be used is more than 50 Hz, a special motor should be used instead of a general-purpose motor. Therefore, a different most suitable motor should be used. When KW indicates the same, the inverter capacity should be increased.</p> <p>Note 2: When the basic frequency and maximum frequency to be used are more than 120 Hz, set F-28 ③ to Fmax 360 (see page 77). (An interlock when a high frequency is selected)</p> <p>Note 3: When a high frequency is to be selected, thoroughly check the mechanical strength of the motor and load.</p>							

V/f Pattern setting



Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal																	
11	(F-10)		Initial set value SEL - S / P      S p e e d	The multistage speed function or the process stepping function is selected, and data is set.																	
			Initial set value (0 Hz) Speed-1 000.0 Hz Speed-2 000.0 Hz Speed-3 000.0 Hz Speed-4 000.0 Hz Speed-5 000.0 Hz Speed-6 000.0 Hz	1) Multistage speed A maximum of 4 stages of operations including the frequency command from the digital operation panel (or external) and Speed-1 to Speed-3 can be performed.																	
		Expansion multistage speed  Data setting 	Speed-1 010.0 Hz Speed-2 020.0 Hz Speed-3 030.0 Hz Speed-4 025.0 Hz Speed-5 060.0 Hz Speed-6 040.0 Hz	SWITCH 2 : { SEL JOG : Jogging mode SEL EXP : Expansion multistage speed SEL JOG is selected (standard setting). }																	
																					
				 <p style="text-align: right;">* -: OFF</p>																	
			<table border="1"> <thead> <tr> <th colspan="2">Terminal</th> <th rowspan="2">Set frequency (Hz)</th> </tr> <tr> <th>CF 1</th> <th>CF 2</th> </tr> </thead> <tbody> <tr> <td>-</td> <td>-</td> <td>Frequency command in the Remote or Terminal mode</td> </tr> <tr> <td>ON</td> <td>-</td> <td>Value set by Speed-1 (1 s)</td> </tr> <tr> <td>-</td> <td>ON</td> <td>Value set by Speed-2 (2 s)</td> </tr> <tr> <td>ON</td> <td>ON</td> <td>Value set by Speed-3 (3 s)</td> </tr> </tbody> </table>	Terminal		Set frequency (Hz)	CF 1	CF 2	-	-	Frequency command in the Remote or Terminal mode	ON	-	Value set by Speed-1 (1 s)	-	ON	Value set by Speed-2 (2 s)	ON	ON	Value set by Speed-3 (3 s)	
Terminal		Set frequency (Hz)																			
CF 1	CF 2																				
-	-	Frequency command in the Remote or Terminal mode																			
ON	-	Value set by Speed-1 (1 s)																			
-	ON	Value set by Speed-2 (2 s)																			
ON	ON	Value set by Speed-3 (3 s)																			




Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal
------------------	------------------------------	---------------	---------	----------------------------


2) Expansion multistage speed

A maximum of 8 stages of operations including the frequency command from the digital operation panel(or external), the jogging set frequency, and Speed-1 to Speed-6 can be performed.

Note : The jogging operation cannot be performed by the multistage speed function. (When the inverter is operated at the jogging set frequency, the jogging operation is not performed but the inverter is operated according to the set acceleration and deceleration time.)



**SWITCH 2 :**  
 [ SEL JOG : Jogging mode  
 SEL EXP : Expansion multistage speed  
 SEL EXP is selected.















\*- : OFF























Terminal			Set frequency(Hz)
CF 1	CF 2	JG	
-	-	-	Frequency command in the Remote or Terminal mode
ON	-	-	Value set by Speed-1 (1 S)
-	ON	-	Value set by Speed-2 (2 S)
ON	ON	-	Value set by Speed-3 (3 S)
ON	-	ON	Value set by Speed-4 (4 S)
-	ON	ON	Value set by Speed-5 (5 S)
ON	ON	ON	Value set by Speed-6 (6 S)
-	-	-	Value set by the jogging set frequency(JG)























FS set in the Terminal mode in the above example





Jogging in the monitor mode

Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal																																	
Multistage speed/process stepping	(F-10)		SEL-S/P Speed	2) Process stepping ① : Maximum frequency 0, 0.5 to maximum frequency ② : Timer time setting 0.1 to 3276.5S ③ : Terminal setting JG-CF1-CF2-2CH ④ : Acceleration or deceleration selection FAD1 : Forward acceleration/ deceleration 1 RAD1 : Reverse acceleration/ deceleration 1 FAD2 : Forward acceleration/ deceleration 2 RAD2 : Reverse acceleration/decelera- tion 2																																	
			SEL-S/P Proces																																		
			Proces1 F000.0Hz																																		
			Proces2 F000.0Hz																																		
			Proces2 F000.0Hz																																		
			Proces2 T0000.0S																																		
			Proces2 TM ---																																		
		Proces2 ADL FAD1																																			
	Data setting		Proces1 F020.0Hz	A maximum of 10 processes are stepped. (5 points from the input terminal) Each process is switched when the preset timer time or the specified input terminal is turned on.  Timer points : 10 points Input terminal : 5 points  Example:																																	
			Proces1 T0000.0S																																		
			Proces1 T0010.0S																																		
			Proces1 T0010.0S																																		
		Proces2 F000.0Hz																																			
	Repeat the same operation	Proces2 F040.0Hz																																			
		Proces2 T0015.0S																																			
Proces2 TM JG																																					
Proces3 F060.0Hz																																					
Proces3 T0005.0S																																					
Proces4 F030.0Hz																																					
Proces4 T0015.0S																																					
				<table border="1"> <thead> <tr> <th>Terminal</th> <th>Process</th> <th>Set frequency (Hz)</th> <th>Timer time</th> </tr> </thead> <tbody> <tr> <td>SWF</td> <td>SWJ</td> <td></td> <td></td> </tr> <tr> <td>ON</td> <td>-</td> <td>1</td> <td>20</td> <td>10</td> </tr> <tr> <td>ON</td> <td>ON</td> <td>2</td> <td>40</td> <td>15</td> </tr> <tr> <td>ON</td> <td>-</td> <td>3</td> <td>60</td> <td>5</td> </tr> <tr> <td>ON</td> <td>-</td> <td>4</td> <td>30</td> <td>15</td> </tr> <tr> <td>ON</td> <td>-</td> <td>5</td> <td>0</td> <td>10</td> </tr> </tbody> </table> <p>Note 1 ←</p> <p>The terminal mode is selected in the above example.</p>	Terminal	Process	Set frequency (Hz)	Timer time	SWF	SWJ			ON	-	1	20	10	ON	ON	2	40	15	ON	-	3	60	5	ON	-	4	30	15	ON	-	5	0	10
Terminal	Process	Set frequency (Hz)	Timer time																																		
SWF	SWJ																																				
ON	-	1	20	10																																	
ON	ON	2	40	15																																	
ON	-	3	60	5																																	
ON	-	4	30	15																																	
ON	-	5	0	10																																	

Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal
			<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">P r o c e s 5 F 0 0 0 . 0 H z</div> <div style="border: 1px solid black; padding: 2px;">P r o c e s 5 T 0 0 1 0 . 0 S</div>	<p>Note 1 : When the timer and the input terminal are set, each process is switched under their logical sum conditions. (Even when the input terminal is turned on prior to the preset timer time, the process is switched.)</p> <p>Note 2 : The process stepping function is performed when the process stepping SLCT PRC is selected from Multistage speed/Process stepping selection in F-30 switch selection 3 ①.</p> <p>Note 3 : The process stepping operation is started by SWF (or SWR). When the digital operation panel is used, press the FWD RUN  (or REV RUN) key .</p> <p>Note 4 : The copy unit is available for Processes 1 to 3 copy but not available for Processes 4 to 10 copy.</p>
12	(F-11)	Frequency stop time adjustment at start  Data setting    	Initial set value(0.0S) <div style="border: 1px solid black; padding: 2px;">F s t o p - T 0 0 0 . 0 S</div>	<p>This is a temporary frequency stop time to prevent an overcurrent of the motor at start.</p>  <p>The stop frequency is about 1/12 of the basic frequency or the minimum frequency whichever higher.            (Invalid when S-Curve is selected)            (Invalid when U-Curve is selected)</p>
			<div style="border: 1px solid black; padding: 2px;">F s t o p - T 0 1 5 . 0 S</div>	
19 20	(F-18) (F-19)	2-stage acceleration time setting 2-stage deceleration time setting  Data setting    	Initial set value(10S) <div style="border: 1px solid black; padding: 2px;">A C C E L - 2 0 0 1 0 . 0 S</div> <div style="border: 1px solid black; padding: 2px;">D E C E L - 2 0 0 1 0 . 0 S</div>	<p>☞ See F-01 and F-02.</p> 
			<div style="border: 1px solid black; padding: 2px;">A C C E L - 2 0 1 0 0 . 0 S</div> <div style="border: 1px solid black; padding: 2px;">D E C E L - 2 0 1 5 0 . 0 S</div>	

Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal
21	(F-20) DC braking frequency adjustment	Data settin    	Initial set value(0.5Hz) F-DCB 000.5 Hz F-DCB 015.0 Hz	When DC braking is selected, the deceleration DC braking start frequency is set. This is a temporary frequency stop time to prevent an overcurrent of the motor at start. When F-DCB is set, the inverter is decelerated at less than the set frequency under the conditions indicated below. ①Both(F-21) V-DCB and(F-22) T-DCB are set. ②F-28① is set to DCB ON(with DC braking). ③The stop command is entered or the preset frequency is 0 Hz. When all ①, ② to ③ are not satisfied, the inverter can be operated down to the minimum frequency.  See ① of F-28 and ① of F-29.
22	(F-21) DC braking power adjustment	Data setting    	Initial set value(0) V-DCB 000 V-DCB 020	The DC braking power is changed. When the set value is 000, the DC braking operation is not started.  See ① of F-28 and ① of F-29.
23	(F-22) DC braking time adjustment	Data setting    	Initial set value(0.0S) T-DCB 000.0S T-DCB 600.0S	The DC braking time is adjusted. When the set value is 000.0S, the DC braking operation is not started.  See ① of F-28 and ① of F-29. 
24	(F-23) Electronic thermal level adjustment	Data setting    	Initial set value(100%) E-therm 100% E-therm 050%	The electronic thermal level can be changed.(100 to 20%)Set the level according to the most suitable current of the motor.  $\text{Adjustment level} = \frac{\text{motor rated current}}{\text{inverter rated current}} \times 100(\%)$  See ④and⑤ of F-29, "Electronic thermal characteristic selection".

Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal															
30	(F-29)		Initial set value(See the indication below) SWITCH2 DB EDG	A specific selection is performed.  ① DC braking DB EDG: Edge operation DB LVL: Level operation  ② Jogging/expansion multistage speed SEL JOG: Jogging mode selection SEL EXP: Expansion multistage speed mode selection  ③ STOP key selection Selection of "validity" or "invalidity" of the STOP key when the operation command terminal mode is selected STOP ON: The <table border="1"><tr><td>停止</td></tr><tr><td>STOP</td></tr></table> key is valid. STOP OFF: The <table border="1"><tr><td>停止</td></tr><tr><td>STOP</td></tr></table> key is invalid.  ④ Electronic thermal characteristic selection Ethm 000 : Reduced characteristics (for general-purpose motor) Ethm 100 : Constant characteristics (for constant torque motor)	停止	STOP	停止	STOP											
		停止																	
		STOP																	
		停止																	
		STOP																	
		Data setting     記憶 STR	SWITCH2 DB <u>L</u> VL																
		  	SWITCH2 <u>S</u> EL JOG																
		Data setting    記憶 STR	SWITCH2 SEL <u>E</u> XP																
  	SWITCH2 <u>S</u> TOP ON																		
Data setting    記憶 STR	SWITCH2 STOP <u>O</u> FF																		
  	SWITCH2 <u>E</u> t h m 0 0 0																		
Data setting    記憶 STR	SWITCH2 E t h m <u>1</u> 0 0																		
Switch selection 2																			
				<table border="1"> <thead> <tr> <th rowspan="2">F-00 V/f pattern setting</th> <th>High start torque</th> <th colspan="2">Standard start torque</th> </tr> <tr> <th>SLV 1, 2</th> <th>VF-VC</th> <th>VF-VP1, 2, 3</th> </tr> </thead> <tbody> <tr> <td>Ethm 000</td> <td style="text-align: center;">✓</td> <td style="text-align: center;">✓</td> <td style="text-align: center;">✓ Note</td> </tr> <tr> <td>Ethm 100</td> <td style="text-align: center;">✓</td> <td style="text-align: center;">✓</td> <td style="text-align: center;">/</td> </tr> </tbody> </table> <p>Note: When VF-VP 1 (VP 2, VP 3) is set, Ethm 000 and Ethm 100 are not displayed since electronic thermal characteristic is automatically selected Ethm 000.</p>	F-00 V/f pattern setting	High start torque	Standard start torque		SLV 1, 2	VF-VC	VF-VP1, 2, 3	Ethm 000	✓	✓	✓ Note	Ethm 100	✓	✓	/
F-00 V/f pattern setting	High start torque	Standard start torque																	
	SLV 1, 2	VF-VC	VF-VP1, 2, 3																
Ethm 000	✓	✓	✓ Note																
Ethm 100	✓	✓	/																



Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal
30	(F-29)		SWITCH2 <u>C</u> MSL OFF	<p>A specific selection is performed.</p> <p>⑤ Commercial operation switching. Whether or not to match the frequency when the commercial operation is switched to the inverter operation is selected. CMSL ON: The frequency is not matched. CMSL OFF: The frequency is matched.</p> <p>⑥ Soft lock selection If SLOK ON is selected while the dip switch LOCK is ON, only the frequency setting is valid. SLOK ON: In the soft lock state, FS cannot be set or changed. SLOK OFF: In the soft lock state, FS can be set or changed.</p> <p>Note: Set this switch before setting the dip switch of the main unit.</p>
		Data setting	SWITCH2 CMSL <u>O</u> N	
				
			SWITCH2 <u>S</u> LOK OFF	
		Data setting	SWITCH2 SLOK <u>O</u> N	
				

Switch selection 2

SWITCH 1

①~⑥

F-28

①	DCB OFF	Without DC braking	See F-20 to F-22.
	DCB ON	With DC braking	
②	FM DIG	Frequency digital monitor	<p>Frequency counter digital monitor A pulse train of a frequency which is the same as the output frequency is outputted. The duty is about 50%.</p> 
	FM ANA	frequency analog monitor	<p>Analog meter monitor A duty (t/T) in proportion to the output frequency is outputted. Adjust the variable resistor (M.ADJ) and the variable resistor of the frequency meter so that the meter indicates the maximum value at the maximum frequency.</p>  <p>Note : • This is a dedicated indicator, so that it cannot be used as a line speed signal.          • Indication accuracy after adjustment : About <math>\pm 5\%</math> (The accuracy of some meter may exceed this value.)</p> <p>(Load resistor 10 to 22k<math>\Omega</math>, 1 mA max., 0 to 10 V full scale)</p>
③	fmax 120	Standard V/f	A frequency of 120 Hz or less (see page 61) is set for V/f pattern selection.
	fmax 360	Special V/f	A frequency of 120 Hz or more (see page 61) is set for V/f pattern selection.
④	PWER ALM	Trip	<p>Standard setting</p> <p>(1) When Ro and To are not connected to power supply.              In other than the cases indicated below, the inverter is tripped and outputs an alarm signal.</p> <ul style="list-style-type: none"> <li>• Power OFF: "POWER OFF" is displayed and the inverter is stopped. (Since it is decided that the power is turned off in the normal state, no alarm signal is outputted.)</li> </ul> <p>(2) When Ro and To are connected to power supply.              An alarm signal is outputted according to instantaneous power failure, undervoltage, or trip contents.</p>
	PWER RST	Auto re-start function	<p>After power is turned on once again, the inverter is decelerated and stopped according to the preset deceleration time.</p> <p>When one of the trips indicated below occurs, a reoperation is performed. (When the frequency is more than 60 Hz, a zero start may result.)</p> <ul style="list-style-type: none"> <li>• Overcurrent</li> <li>• Overvoltage</li> <li>• Undervoltage</li> <li>• Instantaneous power failure</li> </ul> <p>The number of reoperations is 3 times/10 minutes (16 times for instantaneous power failure and undervoltage). In case of instantaneous power failure, the time required for reoperation is set by F-36 (IPS-R-T). For commercial operation switching, see F29 ⑥ of SWITCH 2.</p>

SWITCH 1				
①~⑥				
F-28	④	<b>PWER ZST</b>	Zero start function when the power is turned on again	Zero start when power is turned on once again is set. The contents are the same as those of PWER RST, though a zero start is specified for the reoperation. The time required for reoperation is set by F-36(IPS-R-T). When inertia of the fan is a heavy load, set the time required for the motor shaft to stop by IPS-R-T.
		<b>FWD OFF</b>	Forward operation unavailable	The forward operation command is not accepted.
		<b>FWD ON</b>	Forward operation	The forward operation can be performed.
	⑤	<b>REV OFF</b>	Reverse operation unavailable	The reverse operation command is not accepted.
		<b>REV ON</b>	Reverse operation	The reverse operation can be performed.
		<b>OLMT ON</b>	With overload limit	The overload limit is valid during acceleration or constant speed operation.
	⑥	<b>OLMT OFF</b>	Without overload limit	The overload limit is invalid during acceleration but valid during constant speed operation.

Note : When the auto re-start function is on, the motot is in the free run mode. This function should not be applied to a use requiring a falling object to be held by a mechanical brake during free run.



SWITCH 2

①~⑧

F-29















①	DB EDG	Edge operation		<p>See F-20 to F-22.</p>
	DB LVL	Level operation		
②	SEL JOG	Jogging mode	<p>The inverter can be operated by the frequency command from the digital operation panel(or external terminal)and the multistage speed(Speed 1 to Speed 3)command from a combination of the terminals CF 1 and CF 2 , or by the jogging command from the JG terminal and the expansion multistage speed.</p> <p>See(F-10).</p>	
	SEL EXP	Expansion multistage speed mode	<p>Up to 8-stage speeds including the frequency command from the digital operation panel(or external terminal), Speed 1 to Speed 6 from a combination of the terminals CF 1 and CF 2 , and the JOG multistage speed command can be used.</p> <p>See(F-10).</p>	
③	STOP ON	 Key valid	<p>When the operation command is issued in the Terminal mode, the  key on the digital operation panel is valid.</p>	
	STOP OFF	 Key invalid	<p>When the operation command is issued in the Terminal mode, the  key on the digital operation panel is invalid.</p>	
④	Ethm 000	Electronic thermal relay reduced characteristics	<p>Output current Ethm 100(in the case of a constant torque motor)setting</p> <p>Setting (In the case of a standard motor) (In the high frequency region of more than 60 Hz, the output current is not reduced from 100%)</p>	
	Ethm 100	Output current Ethm 100(for a constant torque motor)setting		




SWITCH 2

①~⑧


























F-29





⑤	CMSL OFF	No commercial power switch over	After the reset is released, the inverter performs zero start. In this case, the commercial operation cannot be switched. About 0.3 sec after the reset is released, the inverter starts outputting.	
	CMSL ON	Commercial power switch over	After the reset is released, the motor speed is detected. When the motor is in the free run state, the inverter starts outputting according to the motor speed. When switching the commercial operation, set CMSL ON. About 1.2 sec after the reset is released, the inverter starts outputting.	
	⑥	SLOK OFF	FS setting, change possible	FS can be set or changed in the soft lock mode(Dip switch LOCK ON).
		SLOK ON	FS setting, change impossible	FS cannot be set or changed in the soft lock mode(Dip switch LOCK ON).







Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal
30	(F-29)	  	SWITCH2 <u>C</u> MSL OFF	<p>A specific selection is performed.</p> <p>⑤ Commercial run selection. When changing from commercial power run to inverter run, select whether frequency matching is performed or not. CMSL OFF: Not perform. CMSL ON: Perform.</p> <p>⑥ Soft lock selection When dip switch LOCK is ON, and SLOK ON is selected, setting frequency is available. SLOK ON: Prohibited to change FS setting in soft lock. SLOK OFF: Possible to change FS setting in soft lock.</p> <p>Note: Set this switch before setting the dip switch of the main unit.</p>
		Data setting	SWITCH2 CMSL <u>O</u> N	
		   		
		Data setting	SWITCH2 S <u>L</u> OK OFF	
		  	SWITCH2 <u>S</u> LOK OFF	
		Data setting	SWITCH2 SLOK <u>O</u> N	
		   		
		Switch selection 2		


Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal
31	(F-30)		Initial set value(See the indication below) SWITCH3 SLCT SPD	A specific selection is performed.
		Data setting 1 2 3 記憶 STR	STITCH3 SLCT PRC	① Multistage speed/process stepping selection SLCT SPD: multistage speed SLCT PRC: process stepping
		1 2 3 記憶 STR	SWITCH3 ORT OFF	② Simple orientation ORT OFF: No orientation ORT ON: Orientation
		Data setting 1 2 3 記憶 STR	SWITCH3 ORT ON	
		1 2 3 記憶 STR	SWITCH3 FARV 2	③ Frequency arrival signal selection FARV 1 : Output at the specified frequency
		Data setting 1 2 3 記憶 STR	SWITCH3 FARV 1	Output frequency Frequency arrival signal 
		1 2 3 記憶 STR	SWITCH3 FARV 1	FARV 2 : Output at a constant speed Output frequency Frequency arrival signal 
		1 2 3 記憶 STR	SWITCH3 STDT RST	④ Initial setting(status before delivery)selection. Selection when returning the inverter to the initial status before delivery for some reason STDT RST: Initial setting invalid (standard)
Data setting 1 2 3 記憶 STR	SWITCH3 STDT SET	STDT SET: Returned to the initial setting The inverter can be reset in the above state.(Between RS and L)		
				
			Note : After reset, STDT SET is automatically changed to STDT RST. Note : See Section 9. 2.	

Switch selection 3







Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal
31	(F-30) Switch selection 3	   Data setting    	Initial set value(See the indication below) <div style="border: 1px solid black; padding: 2px; display: inline-block;">SWITCH3 TRIP OFF</div>	A specific selection is performed. ⑤ Selection of a trip or no trip when an undervoltage or instantaneous power failure occurs during inverter stop TRIP OFF: No trip TRIP ON: Trip
		<div style="border: 1px solid black; padding: 2px; display: inline-block;">SWITCH3 TRIP ON</div>		
32	(F-31) Overload warning level adjustment(optional)	   	Initial setting(100) <div style="border: 1px solid black; padding: 2px; display: inline-block;">OLa l a r m      1 0 0 %</div>	Overload warning can be outputted within an overload range from 50 to 150%. When the load reaches that level, a warning signal is outputted.(Overload warning signal relay output: When an optional PC board is used)  Refer to the function option(A-OP-PCB).
		Data setting <div style="border: 1px solid black; padding: 2px; display: inline-block;">OLa l a r m      1 5 0 %</div>		
33	(F-32) Overload limit constant setting	   	Initial setting <div style="border: 1px solid black; padding: 2px; display: inline-block;">LM. CONS 1 2 5 % 0 1 . 0</div>	This is an overload limit level and overload characteristic constant. This function controls the inverter output current. When the output current exceeds the preset current level as the load increases. The function reduces the number of revolutions of the motor and suppresses an increase in current. ① Selection of over load limit level The set value is adjustable between 50-150% of inverter rated current. When an OC trip often occurs with the standard value set, increase the set value. ② Selection of overload characteristic constant When an OC trip often occurs with the standard value set, decrease the set value.
		Data setting    	<div style="border: 1px solid black; padding: 2px; display: inline-block;">LM. CONS 1 5 0 % 0 1 . 0</div> <div style="margin-left: 100px;">  </div>	
		Data setting    	<div style="border: 1px solid black; padding: 2px; display: inline-block;">LM. CONS 1 5 0 % 0 0 . 5</div>	

Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal						
34	(F-33) Allowable instantaneous power failure time setting	Data setting 	Initial setting(1.0S) 200V class I P S - T 0 0 1 . 0 S Initial setting(0.3S) 400V class I P S - T 0 0 0 . 3 S I P S - T 0 0 3 . 0 S	<p>The time from instantaneous power failure occurrence to recovery is set. When the power failure is recovered within the set time with PWER RST(④ of SWITCH 1) set, the inverter automatically restarts operation. When the digital operation panel or optional PC board is used, or the inverter load is heavy, the inverter display may be erased before recovery even if the power failure is recovered within the preset allowable instantaneous power failure time because the control supply voltage is early dropped. If this occurs, turn power off. An operation same as the restart when the inverter is reset is performed.</p>  <p>See F-28 and F-36.</p>						
		<p>Note: Do not set the instantaneous power failure time 0.4 sec or more for 400V class inverter. When the time is set 0.4 sec or more the inverter does not restart operation.</p> <table border="1" data-bbox="503 840 893 966"> <thead> <tr> <th></th> <th>t(sec)</th> </tr> </thead> <tbody> <tr> <td>200V class</td> <td>0.3~3.0</td> </tr> <tr> <td>400V class</td> <td>0.3</td> </tr> </tbody> </table>				t(sec)	200V class	0.3~3.0	400V class	0.3
	t(sec)									
200V class	0.3~3.0									
400V class	0.3									
35	(F-36) Restart standby time setting after instantaneous power failure recovery	Data setting 	Initial set value(1.0S) I P S - R - T 0 0 0 1 . 0 S I P S - R - T 0 0 0 3 . 0 S	<p>The standby time from instantaneous power failure to reoperation after recovery can be set. When the power failure is recovered within the set allowable instantaneous power failure time set by F-33, the time from recovery to automatic reoperation of the inverter is set. When the inverter starts reoperation, the motor speed is detected. When the motor speed cannot be detected, however, the detection operation is repeated. Therefore, the inverter operates longer than the preset time. When the motor speed cannot be detected, the inverter judges it as a zero start and starts at the start frequency.</p>  <p>See F-28 and F-33.</p>						

Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal									
36	(F-38)		Initial set value(01.5%) BRD-%ED 01.5%	<p>The BRD use rate for 100 seconds is set. When the BRD use rate exceeds this setting, the BRD will not operate.</p>  <p><math>\frac{(t_1 + t_2 + t_3)}{100 \text{ sec}} = T</math></p> <p>When <math>T &gt;</math> the set value, the BRD does not operate.</p> <p>When only the built-in braking resistor is used, the set value should not be more than the value indicated below. Setting value upon shipment from factory.</p> <table border="1" data-bbox="857 682 1367 808"> <tr> <td>Inverter type</td> <td>1.5~3.5LB2 · LD2</td> <td>5.5~16LF2</td> </tr> <tr> <td></td> <td>2.5~3.5HB2</td> <td>5.5~75HB2</td> </tr> <tr> <td>%</td> <td>2</td> <td>1.5</td> </tr> </table>	Inverter type	1.5~3.5LB2 · LD2	5.5~16LF2		2.5~3.5HB2	5.5~75HB2	%	2	1.5
		Inverter type	1.5~3.5LB2 · LD2		5.5~16LF2								
	2.5~3.5HB2	5.5~75HB2											
%	2	1.5											
Data setting	BRD-%ED 02.0%	 <p>Note:When the Optional Regenerative Braking Units is used,set to 31.0. In this case remove resistor built in .</p>											
37	(F-39)		Initial set value(100%) SPD-ARV 100%	<p>The frequency arrival signal is outputted at an optional frequency. The set value is a rate to a maximum frequency of 100%.</p>  <p>Note : Valid when F-30 SWITCH 3 FARV 1 is selected. -0.5 Hz: ON, -1.5 Hz: OFF</p>  <p>*RUN is a running signal, which is outputted when the inverter is in operation.</p> <p>Contact specification. Open collector 27 V, 50 mA max.</p> <p>Forward voltage drop : About 1 V</p> 									
		Data setting	SPD-ARV 050%										


Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal																										
38	(F-40)		Initial set value(See the indication below.) <div style="border: 1px solid black; padding: 2px; display: inline-block;">ORIENT f c 0. 5 H z</div>	<p>The inverter can be oriented. The creep speed and standby time are set.</p> <p>fc : Creep speed Tw : DB signal standby time (DB signal mask time)</p> <p>Note 1 : • An optional PC board (A-OP-PCB) is required. • Valid when F-30 SWITCH 3 ORT ON is selected</p> <p>Note 2 : The POK signal is received and the ORT signal is turned OFF.</p>  <p>Output frequency Time ORT signal DB signal POK signal</p> <p>1 sec</p> <p>Note 2</p> <p>ORT : Orientation start signal DB : Dynamic brake signal</p> <p>Signal to the optional PC board (A-OP-PCB)</p> <p>POK : Orientation completion signal</p>																										
		<p>Data setting</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;">ORIENT f c 9. 9 H z</div> <p>▶ ▶ ▶ ▶ 記憶 STR</p>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">ORIENT Tw 0. 0 1 S</div> <p>▶ ▶ ▶ ▶ 記憶 STR</p> <p>Data setting</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;">ORIENT Tw 9. 9 9 S</div> <p>▶ ▶ ▶ ▶ 記憶 STR</p>																											
39	(F-41)		Initial set value(16KHz) <div style="border: 1px solid black; padding: 2px; display: inline-block;">CARRIER 1 6 K H z</div>	<p>The PWM control carrier frequency can be changed.</p> <table border="1" data-bbox="990 1134 1445 1428"> <thead> <tr> <th rowspan="2"></th> <th colspan="4">kHz</th> <th rowspan="2">Inverter type</th> </tr> <tr> <th>8</th> <th>10</th> <th>12</th> <th>16</th> </tr> </thead> <tbody> <tr> <td rowspan="3">Standard setting</td> <td></td> <td></td> <td></td> <td>✓</td> <td>1.5-22LB2 2.5-22HB2 1.5-16LF2</td> </tr> <tr> <td></td> <td></td> <td>Note)</td> <td>✓</td> <td>33~40HB2 33~50HB2</td> </tr> <tr> <td>Note)</td> <td>✓</td> <td></td> <td></td> <td>60 to 75HB2</td> </tr> </tbody> </table> <p>Note: When the inverter (33~40LB2, 33~60HB2) is used at carrier frequency 16 KHz (12Hz for 75HB2), reduce the rating output current by 10% or use within the range of -10 to 40°C.</p>		kHz				Inverter type	8	10	12	16	Standard setting				✓	1.5-22LB2 2.5-22HB2 1.5-16LF2			Note)	✓	33~40HB2 33~50HB2	Note)	✓			60 to 75HB2
			kHz				Inverter type																							
8	10		12	16																										
Standard setting				✓	1.5-22LB2 2.5-22HB2 1.5-16LF2																									
			Note)	✓	33~40HB2 33~50HB2																									
	Note)	✓			60 to 75HB2																									
<p>Data setting</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;">CARRIER 1 0 K H z</div> <p>▶ ▶ ▶ 記憶 STR</p>																														
40	(F-42)		Initial set value(See the indication below.) <div style="border: 1px solid black; padding: 2px; display: inline-block;">PARAMSET Remote</div>	<p>Whether to set various parameters such as monitor mode <span style="border: 1px solid black; padding: 2px;">モニタ MON</span> and function mode <span style="border: 1px solid black; padding: 2px;">機能 FUN</span> from the digital operation panel or from the external terminal using an optional PC board (A-SC-PCB) can be selected.</p> <p>Note : Valid only when an optional PC board is mounted.</p>																										
		<p>Data setting</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;">PARAMSET Option-b</div> <p>▶ ▶ ▶ 記憶 STR</p>																												



Display sequence	Function code, function name	Key operation	Display	Relationship to I/O signal
41	(F-43)		Initial setting <div style="border: 1px solid black; padding: 2px; display: inline-block;">JMP-WID      0. 3 Hz</div>	The jump frequency range can be set by F-07, F-08, or F-09. The jump frequency width can be changed.  
		Data setting 	<div style="border: 1px solid black; padding: 2px; display: inline-block;">JMP-WID      1. 0 Hz</div>	
Remarks	Copy function		<div style="border: 1px solid black; padding: 2px; display: inline-block;">WRITER REMT→→INV</div>	The preset data(all the data in the monitor and function modes)of the digital operation panel can be transferred to the inverter in a batch. When the  key is pressed, the message on the left is displayed and the data is transferred.
			<div style="border: 1px solid black; padding: 2px; display: inline-block;">WRITER INV→→REMT</div>	The preset data(all the data in the monitor and function modes)of the inverter can be read into the digital operation panel in a batch. When the  key is pressed, the message on the left is displayed and the data is transferred.

## 9.5 Restart after instantaneous power failure and power source switching from commercial power supply to inverter.

### (1) Restart after instantaneous power.



Note: Since retry mode is selected, the inverter is possible to restart when the inverter trips due to overcurrent(OC), overvoltage(OV) and under voltage(UV). Do not use this function for the application that mechanical brake for preventing something falling down is needed while the motor is running free.

Restart will start at the minimum frequency in the following cases.


- ① Setting restart stand-by time to over three seconds(Function mode F-36, IPS-R-T)
- ② Output frequency exceeds 60Hz.
- ③ Output frequency is maximum and the frequency at 60Hz is less than half of the basic frequency.
- ④ The induced voltage of a motor goes down rapidly (For example, the motor speed reduces in less than a few seconds such as pump or high reducing gear.)
- ⑤ The above function F-29 is set from CMSL ON to CMSL OFF.
- ⑥ The keeping time of control power of an inverter depends upon load status, connection of remote operator and deviation of input voltage. It also depends upon model.

Remote operator	Unit:second					
	1.5LB 2	2.5LB 2	3.5~5.5LB 2	8~11LB 2	16LB 2	22~40LB 2
With ※	0.3~1.5	0.3~2.0	0.8~2.0	2.5~6.5	4.5~14.0	1.0~2.0
Without	0.3~2.0	0.4~2.5	1.0~2.5	3.5~7.5	5.5~16.0	1.0~2.0

※ The digital operation panel is equipped(LD2, LF2)

Note 1 : Allowable power failure time set by F-33 can be set to 0.3 to seconds for 200V class and to 0.3 seconds for 400V class. The keeping time of an inverter depends upon model, operation status and input voltage. When the keeping time set by F-33 is used for an interlock, set the shortest time of the above.

Note 2 : When setting other than above is selected. it is reset by OFF. Operation restarts after power come back when operation command is ON.




TO : Allowable power failure time

T1 : Keeping time of control power supply when power supply is shut down

T2 : Setting data in F-33

(2) Power supply switching from commercial power supply to inverter



Connection diagrams and timing charts for commercial power supply switching are shown below.





Figure14 Sample Connection and Timing Charts for Commercial Power Supply Switching

# 10. SPECIFICATION

## 10. 1 Block Diagram



Note : Description of symbols

- (84) : Electromagnetic contactor (Not provided for 1.5 to 2.5LB2)
- DM : Diode module (Converter module)
- CB : Smoothing capacitor
- (28) : Fault alarm relay
- ZNR : Surge absorber
- TRS : Braking transistor (1.5LB2 to 5.5LB2 : (QBR) Mounted on the BRD PC board)
- FAN : 2.5 to 16LB2 : 1pce  
22LB2 : 2pcs 33LB2 : 4pcs
- [---] : BRD PC board
- ZCT : Current transformer
- R-S : Current limiting resistor
- PM : Power module (Inverter module)
- THRY : Temperature detection relay
- CT 2 : Current transformer
- BRDR : Built-in braking resistor (for 3.5 to 40LB2 only)
- T : Transformer (for 400V class)

Note 1 : Only for 16LB2

Note 2 : Transformer is used for 2.5 to 75HB2

Figure 15 Block Diagram

## 10.2 PC Board Layout

The layout of the HFC-VWA PC board is shown below.




Figure 16 PC Board Layout Drawing (Example : 2.5LB2 to 5.5LB2)



### 10.3 Standard Specification

Series name		200 V class HFC-VWA2 series									
Inverter type abbreviation(Type)		1.5LB2	2.5LB2	3.5LB2	5.5LB2	8 LB2	11LB2	16LB2	22LB2	33LB2	40LB2
Protection structure		Fully closed(IP40)			Semi-closed type(IP20)				Open type(IP00)		
Most suitable motor(4 P, kW)		0.75	1.5	2.2	3.7	5.5	7.5	11	15	22	30
Rated capacity (kVA)	200V	1.7	2.6	3.6	5.7	8.3	11	16	22	33	42
	220V	1.9	2.9	4.0	6.3	9.1	12	18	24	36	46
Rated input AC voltage		3-phase 200 to 220/200 to 230V $\pm 10\%$ , 50/60Hz $\pm 5\%$									
Rated output voltage		3-phase, 200 to 230V (corresponding to input voltage)									
Rated output current(A)		5	7.5	10.5	16.5	24	32	46	64	95	121
Control specification	Control method	Space vector PWM control									
	Output frequency range	0.5~360Hz									
	Frequency accuracy	Digital command value $\pm 0.01\%$ of maximum frequency, analog command value $\pm 0.5\%$ (at $25 \pm 10^\circ\text{C}$ )									
	Frequency resolution function	0.01Hz									
	Control characteristics (V/f characteristics)										
	Mean braking torque (TB)										
	Start torque	150% min(1 Hz Hitachi 4-pole general-purpose motor at 200, 220, and 230V)									
	Mean braking torque	(short time)regenerative braking torque %ED set DC braking									
	Overload current rating	150%/60 sec(Once per 10 minutes)									
	Operation specification	Acceleration, deceleration time	0.1S to about 3000S for linear or curve acceleration or deoeleration, individually set for acceleration and deceleration(S-curve, U-curve)								
Multistage speed operation		Max. 8 stages(3 a contact command)									
Jogging operation		0.5 to 9.9 Hz(1 a contact command)									
2-stage acceleration, deceleration		2-stage command for acceleration or deceleration time									
Fault reset		Fault reset, output instantaneous failure(1 a contact command)									
Maximum frequency adjustment		Maximum frequency + 15Hz									
Start frequency adjustment		0.5-5Hz									
Maximum, minimum limiter		Maximum, minimum frequency limiter									
Gain bias function by analog input		Adjustment of start or stop frequency for analog command									
Reclosing during free run		Power can be turned on once again in the motor free run mode.(Zero start in the low speed state)									
I/O signal	Setting	Digital operation panel	Each unit setting, Operation/stop, forward/reverse, (installation and removal available : 0.3m, 1 m or 3 m, with copy function), digital operation panel optional								
		External signal	Current input selection, 0 to 5 VDC, 0 to 10 VDC, 4 to 20 mA								
	Frequency arrival signal	OFF at frequency arrival(open collector output 27 VDC, 50 mA max), OFF for constant frequency, OFF for specified frequency									
	Running signal	ON during inverter running(open collector output 27 VDC, 40 mA max.)									
	Frequency monitor	Analog meter(0 to 10 VDC, 1 mA full scale), monitor by digital frequency counter									
	Free run stop	Output cut-off by external input(1 a contact command)									
	Process stepping control	5 input points, 10 timer points(timer, input terminal logic method)									
Fault display	OFF when the inverter is abnormal or without input power supply(1 c contact output), 3 faults stored										

Series name		200V class HFC-VWA E series									
Protection function	Instantaneous overcurrent	Protection by electronic circuit									
	Overvoltage	The inverter is stopped at a converter output voltage of									
	Undervoltage	The inverter is stopped at an input voltage of about 160V or less									
	Fin overheating	Protection by temperature relay									
	Electronic thermal relay	Time interval electronic thermal relay(20 to 100% can be set.)									
	Restart after instantaneous power failure	The inverter can be restarted after 15ms to 3s.									
		instantaneous power failure is recovered.									
	Overload limit function	The current is controlled by output current detection(The operation level can be set.)									
Ground-fault protection	The inverter is protected by an electronic circuit.										
General specification	Ambient temperature	-10 to 40°C (without terminal cover: -10 to 50°C, storage temperature : -20 to 60°C)						-10 to 50°C (Storage temperature: -20 to 60°C)			
	Humidity	20 to 90% RH(No dew condensation allowed)									
	Vibration	4.9m/s <sup>2</sup> (0.5G)(10~ 55Hz)As per JIS C 0911(1984)						2m/s <sup>2</sup> (0.2G) (10~ 55Hz)			
	Operating site	1,000m or less in altitude, indoors (place free of corrosive gas and dust or dirt)									
	External color	Munsell 10Y3.1/0.3 diecast cases are black corresponding to Munsell N2.)									
Option	Optional PC Board (A-OP-PCB)	Simple orientation, DC brake external command, Inverter output current signal, Relay output of running signal, Relay output of frequency arrival signal, Relay output of overload warning signal									
	Remote operator(DOP)	Installing on front cover(DOP-03EA)…Cable length 0.3m Remote operating(DOP-1 EA, DOP-3 EA)…Cable length 1 m, 3 m									
	Copy unit(DRW)	Easily setting to several inverters(DRW-1 EA)…Cable length 1 m									
Approx, Mass(kg)		6.2	6.2	6.2	6.6	12.0	13.5	19.0	26	26	40

Notes :

The inverter(1.5 to 3.5LD2 and 5.5 to 16LF2) is equipped with a remote operator.

Series name		400 V class HFC-VW2 E series											
Inverter type abbreviation(Type)		2.5HB2	3.5HB2	5.5HB2	8 HB2	11HB2	16HB2	22HB2	33HB2	40HB2	50HB2	60HB2	75HB2
Protection structure		Fully closed(IP40)			Semi-closed type(IP20)			Open type(IP00)					
Most suitable motor(4 P, kW)		1.5	2.2	4.0	5.5	7.5	11	15	22	30	37	45	55
Rated capacity (kVA)	220V/380V	2.5	3.5	5.7	8.6	11	15	21	32	38	49	59	72
	240V/415V	2.7	3.8	6.2	9.3	12	17	23	35	42	54	65	79
Rated input AC voltage		3-phase 380 to 415/400 to 460V $\pm 10\%$ , 50/60Hz $\pm 5\%$											
Rated output voltage		3-phase, 380 to 460V (corresponding to input voltage)											
Rated output current(A)		3.8	5.3	8.6	13	16	23	32	48	58	75	90	110
Control specification	Control method	Space vector PWM control											
	Output frequency range	0.5~360Hz											
	Frequency accuracy	Digital command value $\pm 0.01\%$ of maximum frequency, analog command value $\pm 0.5\%$ (at $25 \pm 10^\circ\text{C}$ )											
	Frequency resolution function	0.01Hz											
	Control characteristics (V/f characteristics)												
	Mean braking torque(TB)												
	Start torque	150% min(1 Hz Hitachi 4-pole general-purpose motor rated Voltage(400, 400V))											
	Mean braking torque	(short time)regenerative braking torque %ED set DC braking											
	Overload current rating	150%/60 sec(Once per 10 minutes)											
	Operation specification	Acceleration, deceleration time	0.1S to about 3000S for linear or curve acceleration or deoeleration, individually set for acceleration and deceleration(S-curve, U-curve)										
Multistage speed operation		Max. 8 stages(3 a contact command)											
Jogging operation		0.5 to 9.9 Hz(1 a contact command)											
2-stage acceleration, deceleration		2-stage command for acceleration or deceleration time											
Fault reset		Fault reset, output instantaneous failure(1 a contact command)											
Maximum frequency adjustment		Maximum frequency + 15Hz											
Start frequency adjustment		0.5-5Hz											
Maximum, minimum limiter		Maximum, minimum frequency limiter											
Gain bias function by analog input		Adjustment of start or stop frequency for analog command											
Reclosing during free run		Power can be turned on once again in the motor free run mode.(Zero start in the low speed state)											
I/O signal	Setting	Digital operation panel	Each unit setting, Operation/stop, forward/reverse, (installation and removal available : 0.3m, 1 m or 3 m, with copy function), digital operation panel optional										
		External signal	Current input selection, 0 to 5 VDC, 0 to 10 VDC, 4 to 20 mA										
	Frequency arrival signal	OFF at frequency arrival(open collector output 27 VDC, 50 mA max), OFF for constant frequency, OFF for specified frequency											
	Running signal	ON during inverter running(open collector output 27 VDC, 40 mA max.)											
	Frequency monitor	Analog meter(0 to 10 VDC, 1 mA full scale), monitor by digital frequency counter											
	Free run stop	Output cut-off by external input(1 a contact command)											
	Process stepping control	5 input points, 10 timer points(timer, input terminal logic method)											
Fault display	OFF when the inverter is abnormal or without input power supply(1 c contact output), 3 faults stored												



Series name		400V class HFC-VWA E series											
Protection function	Instantaneous overcurrent	Protection by electronic circuit											
	Overvoltage	The inverter is stopped at a converter output voltage of about 800V											
	Undervoltage	The inverter is stopped at an input voltage of about 320V or less											
	Fin overheating	Protection by temperature relay											
	Electronic thermal relay	Time interval electronic thermal relay(20 to 100% can be set.)											
	Restart after instantaneous power failure	The inverter can be restarted after a 15ms to 3s											
		instantaneous power failure is recovered.											
	Overload limit function	The current is controlled by output current detection(The operation level can be set.)											
Ground-fault protection	The inverter is protected by an electronic circuit.												
General specification	Ambient temperature	-10 to 40℃ (without terminal cover: -10 to 50℃, storage temperature : -20 to 60℃)						-10 to 50℃ (Storage temperature: -20 to 60℃)					
	Humidity	20 to 90% RH(No dew condensation allowed)											
	Vibration	4.9m/s <sup>2</sup> (0.5G) (10~ 55Hz) As per JIS C 0911(1984)						2m/s <sup>2</sup> (0.2G) (10~ 55Hz)					
		1,000m or less in altitude, indoors (place free of corrosive gas and dust or dirt)											
	External color	Munsell 10Y3.1/0.3 diecast cases are black corresponding to Munsell N2.)											
Option	Optional PC Board (A-OP-PCB)	Simple orientation, DC brake external command, Inverter output current signal, Relay output of running signal, Relay output of frequency arrival signal, Relay output of overload warning signal											
	Remote operator(DOP)	Installing on front cover(DOP-03EA)···Cable length 0.3m Remote operating(DOP-1 EA, DOP-3 EA)···Cable length 1 m, 3 m											
	Copy unit(DRW)	Easily setting to several inverters(DRW-1 EA)···Cable length 1 m											
Approx, Mass(kg)		6.2	6.2	8.5	13.5	13.5	23	28	28	42	42	45	45


Notes :

1. 1.5 to 3.5SBE : Without the Remote Operator  
2.5 to 33 HBE
2. 2.5HDE to 75HFE : With the Remote Operator (DOP-03EA)

## 10. 4 Description of Terminals

	Terminal symbol	Terminal circuit	Description
Control circuit terminal	AR	Frequency arrival terminal	When the frequency reaches the preset value, the transistor output is turned off.
	RUN	Running signal terminal	The transistor output is turned on during running.
	COM	Common terminal	Dedicated AR and RUN common terminal(Not grounding)
	H	Frequency setting power supply terminal	10VDC
	O	Frequency setting terminal	0-10VDC, 0-5VDC(Can be switched by the dip switch): Input impedance : 0-5V(15K $\Omega$ ) 0-10V(30K $\Omega$ )
	OI	Frequency setting terminal	4 to 20 mA(input impedance 250 $\Omega$ )
	L	Common terminal	Common control terminal(Not grounding)
	FM	Frequency monitor terminal	A terminal for the digital frequency counter or the analog meter can be selected.(0 to 10 V, 1 mA full scale, load resistor 0 to 22 K $\Omega$ )
	RS	Fault reset terminal	Contact(closed): Fault signal reset
	FW	Forward operation/stop terminal	Contact(closed):Forward operation, contact(open):stop
	RV	Reverse operation/stop terminal	Contact(closed):Reverse operation, contact(open):stop
	JG	Jogging/expansion multi-stage speed/process terminal	Contact(closed):Jogging operation/expansion multistage speed/process stepping terminal
	L	Common terminal	Common control terminal(Not grounding)
	CF 1	Multistage speed/process terminal	Contact(closed):Multistage speed operation/process stepping input terminal
	CF 2	Multistage speed/process terminal	Contact(closed):Multistage speed operation/process stepping input terminal
	FRS	Free run stop/process terminal	Contact(open):Inverter stop, motor free run stop (the fault is not reset)/process stepping input terminal
	2 CH	2-stage acceleration-deceleration/process terminal	Contact(closed): 2-stage acceleration-deceleration terminal/process stepping input terminal
	AT	Current input selection terminal	Contact(closed):OI terminal input valid Contact(open):O terminal input valid
	USP	Recovery restart prevention(Note 1)	Contact(open):Recovery restart prevention valid Contact(closed):Recovery restart prevention invalid
	AL 1	Fault alarm terminal (Note 2)	Abnormal:AL 0-AL 1 (closed) (See page.57.) AL 0-AL 2 (open)
AL 2	Contact rating:250 VAC, 2.5A(resistor load)0.2A(COS $\phi$ 0.4) 30 VDC, 3 A(resistor load)0.7A(COS $\phi$ 0.4)		
AL 0			



Note 1 : When the power failure frequency and operation command are set, the inverter can start



reoperation when the power failure is recovered. This terminal is used to prevent such an unexpected operation. To start the reoperation, turn the FW, RV signal OFF, and then turn it ON once again or reset the inverter by the RS terminal and turn the FW or RV signal ON.

Note 2 : A relay for the control circuit terminals other than AL 0 to AL 2 should be a weak current relay(12 VDC and 3 mA should be able to be applied).

## 10. 5 Variable Resistor and Dip Switch

	Name	Description
Dip switch		<p>Keep the dip switch OFF.</p> <p>This switch can be used to return the inverter to the initial setting(status before delivery). For details, see Section 9. 2. After operation, turn the switch OFF.</p> <p>Soft lock:When the LOCK switch is turned ON, no data can be changed. See F-29⑥.</p> <p>External frequency setting voltage switching :</p> <p>5 V side: 0 to 5 VDC/ 0 to Fmax</p> <p>10 V side: 0 to 10 VDC/ 0 to Fmax</p>
Potentiometer for adjustment		<p>This can be used for adjustment of an external frequency meter (analog meter). (See page 78.)</p>

## 10. 6 Wiring Instruments

Wiring Instruments and wire thickness are given in the table below. Note that they depend on the wiring length and power supply capacity.

(200V class)

0. 75	HFC-VWA1. 5LB2	2 mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-30F(10A)	H10C
1. 5	HFC-VWA2. 5LB2	2 mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-30F(15A)	H10C
2. 2	HFC-VWA3. 5LB2	2 mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-30F(20A)	H20
3. 7	HFC-VWA5. 5LB2	3. 5mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-30F(30A)	H20
5. 5	HFC-VWA 8 LB2	5. 5mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-50F(50A)	H25
7. 5	HFC-VWA11LB2	8 mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-60F(60A)	H35
11	HFC-VWA16LB2	14mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-100F(75A)	H50
15	HFC-VWA22LB2	22mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-100F(100A)	H65
18. 5	HFC-VWA33LB2	30mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-100F(100A)	H80
22	HFC-VWA33LB2	38mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-225F(150A)	H100
30	HFC-VWA40LB2	60mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-225F(200A)	H125

(400V class)

1. 5	HFC-VWA2. 5LB2	2 mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-50F(10A)	H10C
2. 2	HFC-VWA3. 5LB2	2 mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-50F(15A)	H20C
3. 7	HFC-VWA5. 5LB2	2 mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-50F(15A)	H20C
5. 5	HFC-VWA 8 LB2	3. 5mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-50F(30A)	H20C
7. 5	HFC-VWA11LB2	3. 5mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-50F(30A)	H20C
11	HFC-VWA16LB2	5. 5mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-50F(50A)	H25C
15	HFC-VWA22LB2	8 mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-60F(60A)	H35C
18. 5	HFC-VWA33LB2	14mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-60F(60A)	H50C
22	HFC-VWA33LB2	14mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-100F(75A)	H50C
30	HFC-VWA40LB2	22mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-100F(100A)	H65C
37	HFC-VWA50LB2	22mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-100F(100A)	H80C
45	HFC-VWA60LB2	38mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-255F(150A)	H100C
55	HFC-VWA75LB2	60mm <sup>2</sup> min.	2 mm <sup>2</sup> min.	0. 75mm <sup>2</sup> min. shielding wire	2 mm <sup>2</sup> min.	F-255F(175A)	H125C

Note 1 : The instruments are those for a Hitachi standard 3-phase squirrel-cage motor, 4-pole.

Note 2 : For the circuit breaker, select an instrument suited to its breaking capacity.

Install an earth leakage breaker to avoid an electrical shock.

EX(30, 50B, 60), RX(100, 225) ...for 200V class. EX(50C, 60B), RX(100, 225) ...for 400V class.

Note 3 : When a standard motor (Hitachi standard 3-phase squirrel-cage motor, 4-pole) is used at 10 Hz to 60 Hz, no thermal relay is required.

Note 4 : Give consideration to the power supply system and the wiring system when selecting the breaking capacity.

Note 5 : Use grounding cables 3.5 mm<sup>2</sup> for 8 kVA or higher, and grounding cables in the same diameter as that of the power cable for 5.5kVA or lower.


## 10. 7 OPTIONS

### (1) Remote operator (OPE-4M and OPE-8M)

Standard specifications and internal wiring drawing are shown as below.

Use shield wire connecting a remote operator with an inverter.

Model	OPE-4M	OPE-8M
Protection structure	Fully closed	
Frequency meter	43mm square (0~50 Hz, 0~100Hz; 0~60 Hz, and 0~120Hz are common indication.)	80mm square (0~50 Hz, 0~100Hz, 0~200 Hz; 0~60Hz, 0~120 Hz, 0~240Hz are common indication)
Frequency setting	0.5W 1k $\Omega$	
Switch	FWD/STOP, REV/STOP, JOG (DC10V, 10mA)	
External color	Munsell5Y7/1	



Note 1 : Internal impedance of a frequency meter should be in the range of 10K $\Omega$  to 22 K $\Omega$ .

Note 2 : To adjust a frequency meter, use the potentiometer built in a frequency meter and the potentiometer in an inverter.

### (2) Remote operator (DOP-03A, DOP-1A, DOP-3A) and Digital copy unit (DRW-1A)

When operating the digital operation panel in remote or setting many inverters simply, remote operator and copy unit are available.


See the figure 5 and 6 in attaching a connector.

Follow the instruction manual of a remote operator for detail.


### (3) Function option (A-OP-PCB)

Mounting a PC board (A-OP-PCB) on an inverter extends functions to six kinds, such as orientation function and output.

#### (a) Mounting



(b) CONNECTIONS



Note 1 : CM is a common terminal especially for POK and it is insulated from the other terminals. The terminal is the common terminal for the other terminals, and is also common with the L terminal on the printed circuit board of the main unit of the inverter. Do not ground either CM or L.

Note 2 : Use twisted shield wire for the signal lines.

(c) FUNCTIONS

Function No.	Function name	Terminal used	Contents	Terminal specifications									
①	Inverter output current signal	IM-L	<ul style="list-style-type: none"> <li>A voltage which is proportionate to the output current of the inverter will be output.</li> </ul> <p>Output voltage at the rated current = 4 VDC Accuracy: <math>\pm 0.4V</math> (full range)</p>										
②	Direct current braking external instruction	DB-L	<ul style="list-style-type: none"> <li>By short circuiting DB and L, direct current braking will be forced during deceleration.</li> <li>The optional digital operation panel can be used to make the adjustments in the table below.</li> </ul>										
			<table border="1"> <thead> <tr> <th>Function mode No.</th> <th>Function name</th> <th>Variable range</th> <th>Factory setting</th> </tr> </thead> <tbody> <tr> <td>F-21</td> <td>DC braking power adjustment</td> <td>0 ~ 20</td> <td>0</td> </tr> <tr> <td>F-22</td> <td>DC braking time adjustment</td> <td>0 ~ 15sec</td> <td>0 sec</td> </tr> </tbody> </table> <ul style="list-style-type: none"> <li>By combining with ③ the ORT terminal, this can be used for the orientation function. Refer to function No. ③ for details.</li> <li>If DB and L are short circuited even once during reoperation, then output will remain cut off. This can be released by using reset.</li> <li>When orientation is set, short circuiting DB and L does not cause direct current braking.</li> </ul>	Function mode No.	Function name	Variable range	Factory setting	F-21	DC braking power adjustment	0 ~ 20	0	F-22	DC braking time adjustment
Function mode No.	Function name	Variable range	Factory setting										
F-21	DC braking power adjustment	0 ~ 20	0										
F-22	DC braking time adjustment	0 ~ 15sec	0 sec										
③	Simple orientation	ORT-L DB-L POK-CM	<ul style="list-style-type: none"> <li>By combining this function with the position detector (proximity switch, etc.) on the main spindle of the machine tool, home position stopping of the main spindle can be executed (orientation function).</li> </ul>										
④	Overload warning signal Relay output	OL0-OL1	<ul style="list-style-type: none"> <li>When the overload warning level is reached the contact will close.</li> <li>The overload warning level can be adjusted between 100 to 150 percent of the rating with the optional remote operator (DOP)</li> </ul>										
⑤	Running signal Relay output	RN0-RN1	<ul style="list-style-type: none"> <li>The contact will close during operation of the inverter.</li> </ul>										
⑥	Arrival reached signal Relay output	AR0-AR1	<ul style="list-style-type: none"> <li>When the frequency which is set is reached, the contact will close.</li> <li>The optional digital operation panel can be used to select between constant frequency and designated frequency outputs. Refer to F-30 (3) and F-39.</li> </ul>	<p>Contact specifications AC250V 2.5A (resistor load) 0.2A (cosφ=0.4) DC30V 3.0A (resistor load) 0.7A (cosφ=0.4)</p>									

## 11. ORDERING SPARE PARTS OR REQUESTING PRODUCT INFORMATION

When ordering the spare parts of a product or when requiring information about the product, contact your distributor or a service station in your area with the following information:

- (1) Type
- (2) Output (kVA)
- (3) Manufacturing number (MFG, NO.)
- (4) Fault

When information printed on the nameplate is not readable because the nameplate is old, inform only the clear items with a simple sketch showing the parts required.

To shorten the non-operation time, it is recommended to store the parts in Table 2 on page 31.

### Warranty

The warranty period under normal installation and handling conditions shall be one (1) year after the date of delivery. The warranty shall cover the repair of only the main unit of the delivered inverter.

- In the following cases the repair shall be charged to the purchaser even within the warranty period.
  - (a) Malfunction or damage caused by mis-operation, remodelling, or improper repair
  - (b) Malfunction or damage caused by drop after your purchase or transportation
  - (c) Malfunction or damage caused by fire, earthquake, flood, falling or thunderbolt, natural calamities, pollution, or abnormal voltage
- When the product is to be repaired on your worksite, all expenses associated with field repair shall be charged to the purchaser.
- This manual will not be re-issued. Always keep it at hand. Do not lose it.

Appendix Table 1 List of Alarm Errors

	Panel display	Fault cause	Description	Fault alarm output	Recovery method	
1	Fmax-Fs	$F_{max} < F_s$	Fmax : Maximum frequency + maximum frequency adjusted value	OFF	Correct the frequency. (When the inverter is operated with-out the frequency being corrected, the settings are automatically changed to those in Appendix Table 2. )	
2	Fmax-Fup	$F_{max} < F_{up}$				
3	Fmax-Flw	$F_{max} < F_{lw}$				
4	Fmax-Fm	$F_{max} < F_m$				Fmin : Start frequency
5	Fmax-Fpr	$F_{max} < F_{pr}$				Fup : Maximum limit
6	Fmax-Fes	$F_{max} < F_{es}$				Flw : Minimum limit
7	Fmax-Fee	$F_{max} < F_{ee}$				Fs : Set frequency
8	Fmin-Fs	$F_{min} > F_s$	Fj : Jogging frequency			
9	Fmin-Fj	$F_{min} > F_j$	Fm : Multistage speed			
10	Fmin-Fup	$F_{min} > F_{up}$	Fpr : Process stepping			
11	Fmin-Flw	$F_{min} > F_{lw}$	Fes : External frequency start			
12	Fmin-Fm	$F_{min} > F_m$				
13	Fmin-Fpr	$F_{min} > F_{pr}$	Fee : External frequency end			
14	Fmin-Fcr	$F_{min} > F_{cr}$	Fcr : Orientation creep speed			
15	Fup-Fs	$F_{up} < F_s$				
16	Fup-Fm	$F_{up} < F_m$				
17	Fup-Fpr	$F_{up} < F_{pr}$	Fp : Jump frequency			
18	Flw-Fs	$F_{lw} > F_s$				
19	Flw-Fm	$F_{lw} > F_m$				
20	Flw-Fpr	$F_{lw} < F_{pr}$				
21	Fp-Fs	$F_p - 0.3 < F_s < F_p + 0.3$				
22	Fp-Fj	$F_p - 0.3 < F_j < F_p + 0.3$				
23	Fp-Fm	$F_p - 0.3 < F_m < F_p + 0.3$				
24	Fp-Fpr	$F_p - 0.3 < F_{pr} < F_p + 0.3$				
25	Fp-Fcr	$F_p - 0.3 < F_{cr} < F_p + 0.3$				



Appendix Table .2 List of Alarm Errors Having Values to be Rewritten Forcibly

	<b>Error display</b>	<b>Fault cause</b>	<b>Forcibly rewritten value</b>
1	$F_{max}-F_s$	$F_{max}<F_s$	$F_s \leftarrow F_{max}$
2	$F_{max}-F_{up}$	$F_{max}<F_{up}$	$F_s \leftarrow F_{max}$
3	$F_{max}-F_{lw}$	$F_{max}<F_{lw}$	$F_{lw} \leftarrow F_{max}$
4	$F_{max}-F_m$	$F_{max}<F_m$	$F_m \leftarrow F_{max}$
5	$F_{max}-F_{pr}$	$F_{max}<F_{pr}$	$F_{pr} \leftarrow F_{max}$
6	$F_{max}-F_{es}$	$F_{max}<F_{es}$	$F_{es} \leftarrow F_{max}$
7	$F_{max}-F_{ee}$	$F_{max}<F_{ee}$	$F_{ee} \leftarrow F_{max}$
8	$F_{min}-F_s$	$F_{min}>F_s$	$F_s \leftarrow 0$
9	$F_{min}-F_j$	$F_{min}>F_j$	$F_j \leftarrow 0$
10	$F_{min}-F_{up}$	$F_{min}>F_{up}$	$F_{up} \leftarrow F_{min}$
11	$F_{min}-F_{lw}$	$F_{min}>F_{lw}$	$F_{lw} \leftarrow F_{min}$
12	$F_{min}-F_m$	$F_{min}>F_m$	$F_m \leftarrow F_{min}$
13	$F_{min}-F_{pr}$	$F_{min}>F_{pr}$	$F_{pr} \leftarrow F_{min}$
14	$F_{min}-F_{cr}$	$F_{min}>F_{cr}$	$F_{cr} \leftarrow 0$
15	$F_{up}-F_s$	$F_{up}<F_s$	$F_s \leftarrow F_{up}$
16	$F_{up}-F_m$	$F_{up}<F_m$	$F_m \leftarrow F_{up}$
17	$F_{up}-F_{pr}$	$F_{up}<F_{pr}$	$F_{pr} \leftarrow F_{up}$
18	$F_{lw}-F_s$	$F_{lw}>F_s$	$F_s \leftarrow F_{lw}$
19	$F_{lw}-F_m$	$F_{lw}>F_m$	$F_m \leftarrow F_{lw}$
20	$F_{lw}-F_{pr}$	$F_{lw}>F_{pr}$	$F_{pr} \leftarrow F_{lw}$
21	$F_p-F_s$	$F_p-0.3<F_s<F_p+0.3$	When all of $F_s$ , $F_j$ , $F_m$ , $F_{pr}$ , and $F_{cr}$ are expressed by $F$ , change $F-0.3$ to $F$ . When the result is not satisfactory under another conditions, change $F+0.3$ to $F$ .
22	$F_p-F_j$	$F_p-0.3<F_j<F_p+0.3$	
23	$F_p-F_m$	$F_p-0.3<F_m<F_p+0.3$	
24	$F_p-F_{pr}$	$F_p-0.3<F_{pr}<F_p+0.3$	
25	$F_p-F_{cr}$	$F_p-0.3<F_{cr}<F_p+0.3$	

Appendix Table 3 HFC-VWA Series DATA SETTING LIST

HFC-VWA inverter has many function so that the setting data can be changed by customers. It is recommended to fill the setting data out the following data sheet for service, maintenance and investigating of trouble.

TYPE : HFC-VWA  } Described on spec.  
 MFG. No. :  } label on top cover

● Monitor Mode

Display sequence	Monitor name	Initial display contents	Standard setting	Setting data
1	Frequency setting and output frequency	<u>F</u> S 000.0 00.0Hz	-	
2	Frequency commanding method	<u>F</u> -SET-M Terminal	Terminal	
3	Operation commanding method	<u>F</u> /R-SW Terminal	Terminal	
4	Motor rotational speed display	<u>R</u> PM 4P 00000RPM	4	
5	Frequency converted value display	/Hz 00.0 00000.00	-	
6	Output current display	<u>I</u> f----A Im000.0%	-	
7	Manual torque boost adjustment	<u>V</u> -Boot Code<110>	CONTROL VF	031
			CONTROL <sup>SLV1</sup> or <sup>SLV2</sup>	110
8	Output voltage gain adjustment	<u>V</u> -Gain 100%	100	
9	Jogging frequency setting	<u>J</u> ogging 01.0Hz	1.0	
10	Set parameter Check	CHECK +	-	
11	Forced rewriting of set parameters	FORCE SET +	-	
12	Terminal monitor	TERMINL 00000000	-	
13	Fault display	#	-	
14	Fault trace display	?ERR COUNT 000	-	

● Function mode

Display sequence	Function name	Standard setting	Setting data
1	V/f pattern setting	SLV 1 050-050	
2	Acceleration time setting	10	
3	Deceleration time setting	10	
4	Maximum frequency adjustment	0	
5	Start frequency adjustment	0.5	
6	Maximum frequency limiter setting	0	
7	Maximum frequency limiter setting	0	
8	Jump frequency 1 setting	0	
9	Jump frequency 2 setting	0	
10	Jump frequency 3 setting	0	
11	Multistage speed/process stepping selection	Speed	
	Multistage speed 1 setting	0	
	Multistage speed 2 setting	0	
	Multistage speed 3 setting	0	
	Multistage speed 4 setting	0	
	Multistage speed 5 setting	0	
	Multistage speed 6 setting	0	
12	Start frequency stop time adjustment	0	
13	2-stage acceleration time setting	10	
14	2-stage deceleration time setting	10	
15	DC braking frequency adjustment	0.5	
16	DC braking power adjustment	0	
17	DC braking time adjustment	0	
18	Electronic thermal level adjustment	100	
19	Linear-curved acceleration selection	Linear	

Display sequence	Function name	Standard setting	Setting data
20	Linear-curved deceleration selection	Linear	
21	External frequency setting start	0	
22	External frequency setting end	0	
23	Switch selection 1	DC braking	DCB ON
		Frequency monitor	FM ANA
		Maximum frequency switching	fmax 120
		Restart after instantaneous power failure	PWER ALM
		Operation method designation	FED ON
			REV ON
Overload limit selction	OLMT ON		
24	Switch selection 2	DC braking	DB EDG
		Jogging/expansion multistage speed	SEL JOG
		STOP key selection	STOP ON
		Electronic thermal characteristic selection	Ethm 000
		Commercial operation switching	CMSL OFF
		Soft lock selection	SLOK OFF
25	Swiching selection 3	Multistage speed/process stepping selection	SLCT SPD
		Simple orientation	ORT OFF
		Frequency arrival signal selection	FARV 2
		Initial setting selection	STDT RST
		Trip or no trip selection	TRIP OFF
26	Overload warning level adjustment	100	
27	Overload limit constant	125%01.0	
28	Allowwable instantaneous power failure timer setting	1	
29	Restart standby time setting after instantaneous power failure recovery	1	
30	Regenerative braking use rate setting	1.5	
31	Speed arrival signal optional frequency setting	100	
32	Simple orientation	fc 0.5	
		Tw 0.01	
33	Carrier frequency setting	16	
34	Parameter setting commanding method	Remote	
35	Jump frequency range setting	0.3	

